

Pennine Leisure

Owners Handbook

www.foldingcampers.net

IMPORTANT

Now that you are a proud owner of a Pennine Camper, we are sure that you will get many, many years of enjoyment out of this. You may in the future need help and information on this product and also you may need some optional extra to make your holidays even more luxurious.

When needing this you must first call the No 1 Pennine Dealer for Pennine Campers. Their telephone number is;

01924 - 272877

You will be able to obtain advice and genuine optional extras and any spare part you may require. Also available is the largest range of camping, caravanning and hiking accessories in the country.

Thankyou for your attention. We are the Premier PENNINE Dealer...



Exhibition Centre, Middlestown, Wakefield, West Yorkshire, WF4 4PZ
Telephone 01924 - 272877
www.cgis.demon.co.uk/mitchells/ email:- mitchells.camping@btinternet.com



At Hill House Hammond, we'll make sure your As one of Britain's bigg

At Hill House Hammond, we'll make sure your folding camper insurance is on the right track. We have a dedicated team of specialists who understand what's really important to people looking for no nonsense folding camper insurance cover. No wonder thousands of owners already choose Hill House Hammond.

As one of Britain's biggest insurance intermediaries, we could also help you save on motor, home and travel insurance. Call us now for an immediate quote.

Call: **01285 659685**

Hill House Hammond

Human, helpful and here.

Hill House Hammond Trailer Tent Team, Southway House, South Way, Cirencester, Gloucestershire GL7 1HL.

CONGRATULATIONS

ON YOUR NEW PENNINE!

For any more help, advice or information on Pennine products and service, do call, or drop in to meet our 'Camper Specialists' - David & Sue

Like you, they just love the Pennines!

A warm welcome awaits you at:-



Great Outdoors

Burtree Gate • Darlington • Co. Durham • Tel: 01325 383333

The Great Outdoors on your doorstep!









MOTOR HOMES





OWNER'S DOCUMENT	4	Operation of Submersible Pump - Hints	41
INTRODUCTION & WELCOME	5	Winter Storage (Tiptoe and Submersible Pumps)	41
		Truma- Ultrastore Water Heater	41
THE CAMPER'S CODE	9	Filling Truma Ultrastore with water	42
THE TOWING CODE	10	Draining the Water Heater	42
		Gas Operating Instructions	43
CHASSIS SERVICE AND MAINTENANCE		Electrical Operating Instructions	43
Tyre Information		Maintainance	44
Wheel Changing	19	Safety Notes	44
HITCHING UP – STEP BY STEP	01	Thetford Cassette Toilet	45
		KITCHEN EQUIPMENT	10
ADVICE ON TOWING		Stainless Steel Hob Unit and Sink with Drainer	
ARRIVAL AT SITE	25		
ELECTRICAL SYSTEM	27	Cleaning	
Introduction		Adjusting	49
Standard Wiring Specification		Using Your Hob Safely	49
Electricity Supply Schematic		Spinflo Cooker	
		The Hob	50
12v Electrics		The GrillCleaning	50
Wiring of Connecting Cable for Mains Inlet		Oven	51
Mains Electricity and Connection to On-Site Facility	30	Cleaning	52
Power Management System PMS 4		The Electrolux RM4200 Refrigerator	
Using a Generator	33	LP Gas Operation	
Electrical Control Module ECM5	34		
THE GAS SYSTEM	37	Electric Operation	
Introduction		OPTIONAL BLOWN AIR HEATING	
Gas Regulators		CARING FOR YOUR PENNINE	
Gas Hose		WINTER STORAGE	
		Preparation for Re-use	
Gas System Inlet	3/	SECURITY	
Using LPG Safely	3/	FIRE & SAFETY	65
Calor Gas Information	39	PENNINE OWNERS' CLUB	65
THE WATER SYSTEM	41		

Introduction......41
www.foldingcampers.net

Your supplying dealer should complete this document. It uniquely identifies your camper and should be referred to when requesti service or ordering extras.

Owner's Name	Manufacturer Pennine Leisure Proc
Owner's Address	Model
	Serial Number
	Year of Manufacture
Telephone Numbers	Key Numb <mark>er</mark>
Pre-Delivery Inspection by	
Dealer	Pennine Leisure Products Ltd., Unit 4, Chester Street, Accrington, Lancs BB5 OSD
	Tel: 01254 385991 Fax: (01254) 386111


You are now the proud owner of one of the finest folding campers available. Pennine Leisure Folding Campers are designed for your camping convenience and pleasure and built to the highest standards.

We are sure you will spend many happy hours camping in your new purchase.

This handbook is designed to help you make the most of your camper. Please read it thoroughly and keep it handy for reference.

FOR YOUR INFORMATION – The serial number of your camper is on a plate on the chassis drawbar; the last two digits indicate the model year and the remaining figures represent your camper's serial number (See diagram).

This number must be quoted in all correspondence with your dealer – it uniquely identifies your camper. This plate also states the maximum gross weight of your camper – this weight must not be exceeded.



Important

At various points in this handbook, safety instructions and warnings are given for the protection of you and your family. All such warnings are printed in bold type and preceded by this symbol – !

After Sales Service

All after-sales enquiries must be made to the dealer from whom you bought your camper. This includes enquiries relating to appliances as well as enquiries for optional extras.

Pennine Optional Extras

Your dealer has details of additional items available to enhance your camping enjoyment. These include; awning, underbed skirt or tent, sun canopy, blown air heater, extension for awning, 240v electric hook-up and security safe.

Finally, it is our wish that you derive much pleasure from your Pennine. Read the following pages carefully – they will help you achieve our aim.

Guarantee

Complete this section for your own peace of mind.

NAME AND ADDRESS OF PENNINE DEALER	
TELEPHONE NUMBER	
DATE OF PURCHASE	
SERIAL NUMBER	
KEY NUMBER	

Owner's Service Statement

1. Pennine Leisure Products Ltd (hereinafter called 'the company') warrants that the owner of a folding camper manufactured by the company (hereinafter called 'the camper') will subject to the conditions specified below receive the following service free of all charges (including labour charges) from the authorised Pennine Leisure Products dealer from whom the camper was purchased, namely:-

The repair or replacement of any part (except those mentioned hereafter) of the camper which as a result of defective material or workmanship in manufacture required repair or replacement within twelve months from the date on which the camper was released in a new and unused state by the dealer to its first owner.

The conditions mentioned above are:-

- a) That the camper has not been overloaded or used for racing or time trials or used for hire or reward or otherwise misused.
- b) That the camper has been maintained in accordance with Pennine Leisure Products Owner's Handbook maintenance instructions supplied with each folding camper.
- c) That neither the camper or any part has been altered, modified or repaired without the company's prior written consent.
- d) That the identification numbers of the company on the camper have not been removed or defaced.
- e) That the camper has not been used on roads or in conditions not suitable for a folding camper.
- f) That the owner notifies the authorised dealer of the alleged defect within fourteen days of discovering it (the notification should be in writing and should specify the brand and model name and serial number of the camper and the supplying dealer's

name) and give sufficient particulars to enable the matter complained of to be identified.

- g) That the camper is used only in the United Kingdom (other than temporary removals outside the United Kingdom for the purpose of a holiday or business tour).
- h) That the camper is towed by a motor car. If the camper is towed by another vehicle, commercial or otherwise, fitted with a 'rigid' towbar the suitability must be accepted in writing by Pennine Leisure Products prior to commencement of warranty.

The excepted parts referred to are chassis, tyres, hubs, couplings and propriety products such as cookers, refrigerators and heaters normally covered by the respective manufacturer's own guarantee.

The warranty terms do not cover the cost of returning the camper to the place of repair.

- The company's agents have no authority to vary the terms of this statement.
- 3. In this statement, the words 'the owner' means the purchaser or the hirer under a hire purchase agreement and the words 'authorised dealer' means a person, firm or company under contract with Pennine Leisure Products Ltd to supply or service Pennine Folding Campers.
- 4. Nothing in this Owner's Service Statement affects the owner's statutory rights in respect of the camper.

FOR THE BEST DEALS ON TRAILER TENTS AND FOLDING CAMPERS

- Large, well stocked accessory showrooms
- NCC approved caravan repairs
- Huge selection of new and used tourers, holiday homes (Ebor and Huddersfield) and Motorhomes (Huddersfield only)



Unique to Countrywide Leisure the new

PENNINE PATHFINDER 600XL

Holiday in style with this superb folding camper that offers you a unique level of specification at an excellent price

Features include:

- Oven
- Cassette Toilet
- Hand Basin
- Mains Electrics
- Battery Locker
- Shelf Unit and External 240v Socket
- Underbed Skirt
- Al-Ko AK1300 Stabiliser
- Al-Ko Side Lift Jack
- 4 Scatter Cushions
- Full Awning
- Unique Graphics
- Water Heater



Pennine Leisure

Available at Ebor & Kirton Only

EBOR CARAVAN CENTRE

Malton Road, Flaxton Moor, York, North Yorkshire Tel: 01904 468334

HUDDERSFIELD CARAVAN CENTRE

Crosland Hill, Huddersfield, West Yorkshire Tel: 01484 642613

KIRTON CARAVAN CENTRE

Station Road, Kirton Lindsey, Lincolnshire Tel: 01652 648569

LEEDS CARAVAN CENTRE

York Road (A64), Scholes, West Yorkshire Tel: 0113 232 3586

RENISHAW CARAVAN CENTRE

2 Smithy Brook Road, Renishaw, Sheffield, North Derbyshire Tel: 01246 435761

SPONDON CARAVAN CENTRE

Nottingham Road, Spondon, Derby, Derbyshire Tel: 01332 663191





GOLDCARE FOLDING CAMPER INSURANCE

- The only policy recommended and endorsed by the National Caravan Council
- Wide All Risks Cover especially designed for Folding Campers and Personal Luggage and Effects
- Low premiums with discounts for new owners e.g. - Camper & Luggage - Value £6,000 Premium £102 plus IPT

Contact

Coyle Hamilton Insurance Brokers Ltd 325-331 High Road, Ilford, Essex, IG1 1UJ

Tel 0208 514 3333 Fax 0208 553 3189

quoting reference PCH1

THE CAMPER'S CODE

On The Road

The camper complies with the Road Traffic Acts and Regulations. Its weight distribution and undergear are not such as to cause undesirable swaying.

The owner ensures that it is insured against third party risks and that the car policy is not invalidated by towing.

The camper causes as little inconvenience as possible by looking out for and giving way to faster traffic.

He allows himself ample safety margin for stopping and changing direction.

He keeps close to the left, but is careful not to return too quickly to the left after passing cyclists or other traffic.

He does not tow a camper so large and heavy that the towing car cannot hold it steady under normal conditions, without snaking, or cannot climb ordinary main road hills without failing and obstructing other traffic, or cannot pull it up in adequate distance under braking.

On The Site

The camper does not stop on private land without obtaining the permission of the owner.

He places his camper where it will not interfere with the convenience or enjoyment of others.

He keeps his pitch neat and tidy with no loose equipment outside the camper beyond what is necessary or appropriate, and he leaves his pitch as clean or cleaner than he found it.

On organised sites he disposes of all rubbish by the means

provided and on casual sites he buries it or takes it away for disposal elsewhere in the proper manner.

He collects waste water from the camper waste outlet in a receptacle which he does not allow to overflow and foul the ground. On organised sites he disposes of waste water in the manner provided for and on casual sites he minimises fouling of the ground, e.g. by distributing waste water along a hedge.

He does not damage the turf by digging unnecessary holes or by improper use of his car.

For touring he carries his own sanitary equipment, comprising a chemical closet and suitable fluid. He does not rely on the earth method except at casual sites in very remote country. When the contents of a chemical closet are disposed of by burial, he avoids the vicinity of any watercourse.

At organised sites he keeps his dog under proper control, drives very slowly through the caravan lines, and avoids singing, loud radio, electric generator or any other noise at an hour where it would reasonably annoy others.

He makes sure that any laundry necessarily hung outside the camper is displayed discreetly.

He observes the country code relating to fire dangers, litter, gates, damage to crops, hedges, trees and livestock.

General

The camper shows courtesy and consideration to all with whom he comes into contact, so that the goodwill of campers is enhanced and he pays his proper dues.

THE TOWING CODE

This Code of Practice contains recommendations jointly reviewed and agreed by the following organisations:

The National Caravan Council, The Caravan Club, The Camping and Caravanning Club, The Caravan Writers Guild, The Department of Transport.

Scope of the Code

The code applies to all trailer caravans and campers of maximum laden weight not exceeding 2030kg (4475lbs), overall width not exceeding 2.3m (7ft 6in approximately) and overall length not exceeding 7m (23ft approximately), excluding the drawbar and coupling.

This is legally the maximum size of trailer that can be towed by a motor car. (Regulations 7 & 8 of the Road Vehicles (Construction & Use) Regulations 1986).



CARAVAN / CAMPER TERMS

Ex Works Weight:

The maximum weight of the camper as stated by the camper manufacturer, as new with standard fixtures and fittings. (Note: because of the differences in weight of materials supplied for

construction of the camper, variation of $\pm 5\%$ of the manufacturer's stated ex works weight can be expected).

Actual Laden Weight

The total weight of the camper and its contents when being towed.

Maximum Authorised Weight (MAW):

The maximum weight for which the camper is designed for normal use when being towed on a road laden. This figure must not be exceeded (See page 11)

Noseweight:

That part of the weight of the caravan supported by the rear of the towing vehicle.

The Towing Vehicle Kerb Weight

The weight of the towing vehicle as defined by the vehicle

This is normally:

with a full tank of fuel; with an adequate supply of other liquids incidental to the

vehicle's propulsion; without driver or passengers;

without any load except those tools and equipment with which

the vehicle is normally provided; without any towing bracket.

Camper / towing vehicle weight ratio:

The actual laden weight of the camper is expressed as a percentage of the kerb weight of the towing vehicle, ie.

actual laden weight of caravan

Kerb weight of towing vehicle.

X 100 = %

FACTORS WHICH MUST BE CONSIDERED FOR SAFE TOWING

Driver's towing experience

Experience of towing is not essential for taking up caravanning but drivers without experience should take greater care when manouvering. Speed should be built up gradually to get used to the different braking and handling characteristics.

Further experience should be gained before tackling the more advanced elements of towing (higher weight ratios, mountain passes, difficult terrain, etc.)

CAMPER / TOWING VEHICLE WEIGHT RATIO

This ratio has a major influence on stability. It is recommended that: The actual laden weight of the camper should be kept as low as possible. The lower it is when the camper is being towed on a road the safer the camper/towing vehicle combination will be.

Ideally, for a newcomer to caravanning the actual laden weight of the camper should not exceed 85% of the kerbside weight of the car.

As a general guide, the actual laden weight of the camper should not exceed the kerb weight of the towing vehicle if the latter is a conventional car (saloon, coupe, hatchback, estate convertible etc)

The greater the actual laden weight of the camper is in relation to the kerb weight of the towing vehicle, the more careful and experienced the driver needs to be.

Care must always be taken not to exceed the towing vehicles loading and towing limits.

The law requires that caravans and their towing vehicles and the loads they carry must be in such a condition that no danger or nuisance is caused.

(Regulation 100 of the Road and Vehicles (Construction and Use) Regulations 1986)

POWER TO WEIGHT RATIO OF TOWING VEHICLE TO CAMPER

The performance of the towing vehicle has an important bearing on its suitability for towing and, therefore, on the selection of the camper to match the towing vehicle.

There are many factors involved, which are often contradictory, such as brake horse-power, gearing, torque characteristics, turbo charging and fuel injection.

No hard and fast rules can be stated but, as a general guide, conventional petrol engines with a capacity up to approximately 1500cc should be adequate for towing a camper weighing around 85% of the kerb weight of the towing vehicle. Above 1500cc such engines should manage a camper weighing up to 100% of the kerb weight of the towing vehicle and still give adequate performance, but it should be noted that the towing vehicle manufacturer's limit is, in some cases, less than the kerb weight. While the towing vehicle may manage 100%, attention is drawn to the recommendation under the previous heading 'camper/towing vehicle weight ratio', that a weight ration of 85% is an ideal starting point.

Diesel engines of whatever size have a lower performance for a given cubic capacity compared to petrol engines.

When climbing a 10% loss of power with a petrol engine and slightly less with a diesel engine should be expected for every 1000 metres gain in height. A good reserve of power is therefore very necessary for towing up gradients at altitude.

Vehicles with automatic transmission may need additional cooling for the gearbox when towing. The advice of the vehicle manufacturer should be sought.

Vöhringer

1921-1996

75th Jubilee

Are pleased to be suppliers to

PENNINE LEISURE PRODUCTS LIMITED

And wish them continued success.

Vöhringer

Manufacturers and suppliers to the International Leisure Industry.

Laminators of Sheet Materials – PVC, Vinyl and Paper Overlays, Wrapped Mouldings.

UK Sales Office I Butterwick Drive, Shrewsbury SYI 3XE Telephone 01743 350580 Facsimile 01743 362322

Breckland LOCKFAST

Wheel Lock
for caravan & trailer security



Features:

- Original Heavy Duty Wheel Lock, offering high security.
- Unique, High Security, drill resistant, Push Button Lock System.
- Simple and quick to fit. It can literally be fixed to a wheel in 3-4 seconds.
- Provides immediate security, any time a caravan or trailer is parked.
- Precision Engineered. Moderate weight of 3.5Kg.
- Practical size for easy storage and use at any time.
 for example any temporary stop such as motor way services, when a caravan can be very vulnerable. Many traditional wheel clamps are simply too cumbersome to be used in this way.
- High visual deterrent. Anti-corrosion pretreatment; Bright Yellow Epoxy finish.
- Model LF100 for 100mm bolt /nut PCD (use with Pennine Camper).
- Model LF55 for 5.5" bolt /nut PCD.
 Both models are supplied with 2x Special 12mm bolts which replace two of the standard wheel bolts, to which the LOCKFAST Wheel Lock attaches.
- Insurance approved. Recommended by Crime Prevention Officers in several police forces.
- Pedigree of the LOCKFAST:

Patent Pending

The manufacturers invented and have produced the ORIGINAL Quick Release Leaf Spring Stabiliser since 1984.

Our DRIVER and CORGI Stabilisers have always been superior in quality and value.

*© (1983) The copyright of the name Quick Release Stabiliser is the intellectual property of Beckland Trading Co.

LOCKFAST for caravan and trailer security

Breckland Trading Company, Croxton, Thetford, Norfolk, IP24 1NQ Tel:01842 754900 Fax: 01842 753007

BRAKE FAULTS AND THEIR ELIMINATION

FAULT	CAUSE	ELIMINATION	
Braking Effect	Too much play in the brake system.	Re-adjust the brake system.	
Section (1997) (1997) (1997) (1997)	Brake linings not run in.	Tighten somewhat the handbrake lever, drive 2-3 km	
	Brake linings smooth, oiled or damaged	Replace brake shoes completely. Clean the braking surfaces in the brake drums.	
	Over-running hitch is tight.	Lubricate the over-running hitch.	
	Brake rod skewed or bent.	Eliminate the cause.	
	Brake cables rusty or buckled.	Replace the brake cables.	
Jerky Braking	Too much play in the brake system.	Re-adjust the brake system.	
1000000 A 201000000000000000000000000000	Shock absorber of over-running hitch defective.	Replace shock absorber.	
	Backmat brake shoe skews in the brake shoe carrier.	Replace complete brake shoe with brake shoe carriers.	
Trailer already brakes when relieving the foot throttle.	Shock absorber of over-running hitch defective.	Replace shock absorber.	
p · · · I I · · · · · · I I	Brake system adjusted too severely.	Readjust the brake system.	
Reversing is hard or impossible	Cables pre-tensioned	Readjust the brake system.	
	Incorrect adjustment	Readjust the brake system.	
Handbrake effect too weak		Tighten handbrake lever as far as possible.	
Wheel brakes get hot.	Incorrect adjustment of brake system.	Readjust the brake system.	
	Wheel brakes dirty.	Clean.	
	Handbrake lever not or only partly released.	Bring handbrake lever in zero position.	
Ball coupling doesn't rest on ball Inside of coupling dirty.		Clean out.	

AL-KO KOBER CHASSIS

Description and Operation

The chassis is made of heavy duty galvanised steel.

Coupling Head

The ball couplings are entirely automatic in operation and designed for one hand operation to suit the 50mm international ball recommended by the British Standards Institution, National Caravan Council and the Society of Motor Manufacturers and Traders. The coupling head incorporates a 'positive attachment indicator button' designed to assist correct attachment. In addition there is provision for an anti-theft device consisting of a brass bawel lock which when inserted into the coupling head prevents movement of the handle, therefore making it impossible to lock the coupling either 'on' or 'off' the towing ball.

Coupling Up

Reverse the car to the trailer or move the trailer forward to the coupling point. Lift the locking trigger, and lift the handle upwards and forwards. Place the unlocked coupling onto the towing ball and with the slightest downward pressure it will lock onto the ball automatically. Ensure locking trigger returns to its free position. Connect the breakaway cable and lighting plug to the towing vehicle. Raise the jockey wheel to its stowed position.

Uncoupling

Lower the jockey wheel to the ground. Disconnect the breakaway cable and lighting plug.

Operate the handle and manually lift the coupling head clear of the towing ball or raise the telescopic jockey wheel to achieve the same effect. The trailer towing ball coupling of the chassis has been type tested; the maximum support load at the coupling point must not be exceeded.

The Axle


The AL-KO rubber suspension axle has been designed for new standards of spring comfort and is maintenance free.


Three rubber elements are contained within an hexagonal axle tube. These provide suspension and have inherent damping characteristics.

The following three figures show the deformation of the rubber elements at the extremes of suspension movement.

The axle is designed to ride with the suspension drop arm at, or slightly below, the horizontal position.







The AL-KO automatic reversing wheel brake system comprises, twin brake shoes acting against a drum. The shoes are actuated by a fully floating expanding clutch, which when operated forces the shoes into contact with the drum.

The system also contains an adjuster box to arrest directional motion of the expanding clutch and shoes when the brake is engaged and a spring loaded reverse lever which collapses when reverse travel is required.

Operation

Forward braking; in the free position, with the handbrake fully forward in the off position, the drawshaft of the over-run device is fully extended and the shoes are clear of the drum.

As the towing vehicle brakes, the drawshaft of the over-run device is depressed toward the unit being towed. This action imparts linear motion to the main shaft of the over-running device which is transmitted via the over-run lever, brake rod and Bowden cable to the expanding clutch. This mechanism forces the leading brake shoe and, by reaction, the trailing shoe outwards into contact with the drum.

Friction between the brake shoes and the drum creates a tendency for both shoes and the expanding clutch to move in the direction of forward rotation until they abut against the adjuster box. This ensures that both shoes remain in the braking position.

Reversing

When the towing vehicle reverses, the drawshaft is pushed backward, moving the over-running device through its full travel. This movement is transmitted in the normal manner to the expanding clutch.

The clutch forces both shoes into contact with the drum. Initial

friction between these creates a tendency for the shoes and expanding clutch to move in the direction of wheel rotation ie. reverse. This movement imparts pressure to the spring-loaded auto-reverse lever, causing it to collapse. Thus, friction between the shoes and drum is almost eliminated, allowing the trailer to reverse in contact with the towing unit.

Slight forward movement of the chassis will allow the spring to reassert itself, enabling the reverse lever to recover to its normal position. Normal braking is then immediately available.

Parking - Handbrake Application

The AL-KO automatic reversing brake system incorporates a patented device for added safety when parking on a reverse sloping site or steep hill.

A spring cylinder has been added to the link between handbrake lever and centre brake rod.

Full application of the handbrake lever compresses a coil spring inside a steel cylinder and should any movement of the caravan occur following uncoupling the energy stored in the spring is immediately released to lock the wheel brakes.

The handbrake should always be applied to the full vertical position. Should any difficulty be experienced in achieving this position, gently inch the caravan backwards whilst applying the handbrake.

It should be noted that it is good practice to chock the wheels of a caravan when parking on steep slopes, or under adverse conditions such as loose or slippery surfaces.

Tyre Wear and Damage

The legal requirements for tread depth on motor vehicle tyres applies also to caravans. Similarly it is not permitted to mix cross ply

and radial tyres on the same axle. A redundant tyre must be replaced by one of the same size and construction.

Wheels should be balanced and changed round occasionally to equalise wear and prolong the life of the tyres.

It is very dangerous to neglect tyre damage. A tyre should be renewed if a blister, rupture or cut exposing the casing is detected. If the tyre has suffered violent impact (eg. against a kerb) it should be examined by a specialist as soon as possible.

SERVICING

Servicing Philosophy The chassis has been designed to be maintained at its optimum

performance level with minimal servicing. Servicing philosophy embraces lubrication, inspections and adjustments carried out in accordance with a schedule based on mileage. However, if the mileage is not attained, servicing should be carried out on a periodic basis.

Servicing Schedule

After First 500 Miles:

- Check wheel bearing adjustment.
- Check and adjust the brake shoes and the brake linkage.

Every 500 Miles or 2-monthly

- Inspect all wheels.
- Examine and lubricate the ball coupling.

- Inspect and lubricate the over-running device.
- Lubricate the jockey wheel.
- Lubricate the brake linkage.
- Lubricate the corner steadies.

Every 3000 Miles or Annually

- Measure the towing ball.
- Grease the over-running device.
- Check and adjust the brake shoes and the brake linkage.
- Grease the torsion bar axle.

Every 6000 Miles or Bi-annually

- Adjust the axial play of the wheel hub bearings.
- Check the brake linings and brake shoes pull-off springs for wear or fatigue.
- Check and adjust the brake shoes and the brake linkage.
- Grease the running nuts on the brake linkage.
- Lubricate the pivot points of the running brake system.

After Use Servicing

After journeys during winter, hose down the chassis to wash the road salt off.

Recommended Lubricants

Mobilgrease MP is recommended for all greasing routines. A good all-purpose oil is recommended for general use.

BRAKE DRUM / HUB ASSEMBLY

Your chassis uses the new AL-KO Euro-axle system incorporating sealed for life bearings which are maintenance free and have a design life of 100,000km (62,000 miles). Do not attempt to remove

or replace this bearing if it, or the drum, are damaged then it will be necessary to replace with a complete drum and bearing assembly. If it is necessary to remove the brake drum, the following procedure should be followed (we recommend this to be carried out by an accredited AL-KO Service Centre):

- 1. Remove dust cap.
- 2. Remove flanged hub nut. Note: This is a 'one shot' nut, when re-fitting brake drum a new flanged nut MUST be used.
- 3. No greasing of hub bearing is required nor should the dust cap be packed with grease as on previous designs.
- 4. Re-assembly is the reverse procedure, however, the stub axle thread must be coated with 'Indol' mineral grease (available from AL-KO prior to fitting the new flanged nut. This nut must be torqued to 290Nm±10Nm (214lb/ft±7.5lb/ft).

Under no circumstances should the rear stub nut be disturbed as this controls toe in and camber. Interference with this nut will invalidate warranty. If it is, for any reason, disturbed then the axle must be returned to AL-KO for resetting of toe in and camber.

Check and adjust the brake shoes and the brake linkage. The AL-KO automatic reversing brake system and its linkage should be periodically adjusted to compensate for wear of the break shoe lining and subsequent stretching of the Bowden cables.

The trailer brake will be subject to greater wear when used on continuous mountain journeys. The corner steadies should never be used to jack up the unit. When jacking becomes necessary, place the jack into the jacking point fitted on the camper.

NEVER USE THE CHASSIS MEMBERS AS A JACKING POINT

Recommended Adjustment Procedure


- a) Jack up the axle to raise the road wheel clear of the ground.

 Place a chock under the grounded wheel.
- b) Ensure that the drawshaft is fully extended (in the towing position) and the handbrake is OFF (fully forward position). Confirm that there is some end float in the rod and spring cylinder.

The brakes must be adjusted first and then, but only if necessary, the brake linkage.

During wheel brake adjustment, the drum must only be turned in the direction of forward rotation.


Do not use excessive force during adjustment.



- c) Remove the plastic bung at the rear of the brake back plate and insert a suitable screwdriver into the hole.
- d) Adjust the star wheel in the direction of the arrow until there is resistance to wheel movement.
- e) Slacken until the brake drum turns freely in the forward direction.
- f) Check for correct adjustment at the chassis end of the Bowden cable. When pulled the cable should extend between 5 and 8mm. WWW.foldingcampers.net

17

g) Check for uniform response by both wheel brakes when the hand brake is operated. Adjustment must be made on the wheel brake, not on the brake linkage.



- h) Apply the handbrake two or three times to ensure that the brake shoes are centralised on the drum. Re-check shoe clearance at the wheel brake.
- i) Centre brake rod check that there is full thread engagement in the fork end of the over-running device. Secure the locking nut.
- At the axle, ensure that the compensator plate is parallel to the axle by adjusting the nuts on the Bowden cables. Lock the nuts.
- k) Adjust the centre brake rod at the rear nut so that there is no clearance between the over-run lever and the drawshaft and plate. Secure the locknuts.
- Correct adjustment of the linkage is checked by operating the handbrake lever so that it engages the second tooth of the ratchet and confirming that a slight braking force is felt at the wheels.
- m) On completion, tighten the self locking nut to give 1mm clearance between the nut and the spring cylinder. (Ignore this instruction if a gas strut type handbrake lever is fitted.)

Reversing will be difficult if either the wheel brake or the brake linkage is over adjusted.

Examine and Lubricate the Ball Coupling

- a) Examine all moving parts and the locking feature for wear and correct operation.
- b) Clean off and grease the spherical seat, bearing points and pivot pins.

Torque settings for securing bolts of ball couplings:

9OS-AK10	 	80Nm (18lbf)

Examine and Lubricate the Over-Running Device

- a) Examine all pivot pins and levers for correct operation and lubricate with oil.
- b) Check the handbrake ratchet for correct operation and lubricate with oil.

Lubrication

Lubricate the Jockey Wheel - lightly oil the wheel axle and screw thread.

Lubricate the Brake Linings – Lightly oil all moving parts.

Lubricate the Corner Steadies - Lightly oil the screw and pivot points.

CHECK THE WHEEL NUTS

BEFORE STARTING EVERY JOURNEY.

SERVICING AND TYRE INFORMATION

Recommended Servicing

As with your car, regular servicing of your camper's braking system, wheels/tyres and road lights are important, to maintain its optimum performance, investment value and most of all, safety.

Owners are strongly recommended to have their campers serviced prior to winter storage and before the start of the camping season.

Regular servicing of your camper can prevent accidents and it is the responsibility of the owner to ensure this is carried out.

Tyre Information

Model	Maximum	Tyre	Psi
	gross weight	size	max
Apollo	700	155R1378	32/35
Fiesta	<i>75</i> 0	1 <i>55</i> R1378	32/35
Sterling	850	155R1378	32/35
Pullman	900	155R1378	32/35
Pathfinder	1000	165R1382	33/36
Aztec	600	145R1068	35/35

The first figures shown for load and pressure are applicable for 130kmh, the second figure 100kmh.

Please note that tyre pressures are maximum permissible and products supplied will be inflated accordingly. A reduction in pressure may be applicable if maximum tyre load is not utilised.

Your camper tyres must be at the pressure shown above. The correct pressures for your towing vehicle will be found in the vehicle's handbook, BUT it is recommended that an extra 4 to 6psi is put into the rear tyres of the vehicle to improve handling and to bear the extra load on the hitch.

Pressure should be checked with the tyres cold, not after a run when the pressure will be higher. Never reduce the pressures when the tyres are warm as they could be too low when they cool down.

If your camper should have a puncture, replace the affected wheel only with the correct spare wheel and tyre, which can be found in a carrier underneath the camper chassis.

Check your tyres regularly, but particularly if the camper has not been used for a long time. In order to minimise wear, it is recommended that wheels be balanced.

4WD Lightweight Commercial Vehicles

We would strongly recommend that any caravanner who uses either a 4WD (ie Landrover, Shogun etc) or a lightweight commercial vehicle should use a spring assisted towball. The unit will reduce the shock put into the system by between 50% and 70%.

This unit is already a standard factory fitted optional extra for such manufacturers as Diahatsu and Isuzu and more are considering the 'Shocklink'.

Wheel Changing

In the event of a puncture, the affected wheel will need to be changed in the following manner;

- Apply the handbrake fully, as for parking. Remove the wheel trim if fitted.
- 2) Slacken off the wheel bolts on the wheel to be changed.
- 3) Jack up the camper with the jack under the axle tube or axle mounting plate, using a bottle jack or scissor jack if available. If such a jack is not available, alternative methods of raising the wheels off the ground are given below.
- 4) Remove the wheel bolts and the wheel.

- 5) Locate the spare wheel carrier under the chassis at the rear of the camper. Remove the 'R-clip' and wing nut. Slide the carrier forwards and lower the carrier and wheel to the ground and remove the wheel.
- 6) Check the condition of the spare wheel before fitting. Check all mating surfaces are clean and dry, including the bolt seats. Always use the correct bolts to secure the wheel.
- 7) Fit the spare wheel and refit the bolts, finger tight to begin with. Using a car wheel brace, fully tighten the bolts in diagonal pair to ensure the wheel is correctly seated. Ideally the bolts should be tightened to a torque of 65lb/ft. If it is not possible to check this, (ie. at the roadside), have the torque checked at the first opportunity.
- 8) Lower the camper to the ground. Check the wheel bolts for tightness after 20 miles and every 3,000 miles thereafter.
- Stow the damaged wheel in the spare wheel compartment and make sure it is repaired or replaced as soon as possible.

If you do not have a jack: In the case of the Pullman and the Sterling, the affected wheel may be raised by winding down the corner steadies on that side evenly (ie. wind one turn on each steady alternately) until the wheel is clear of the ground.

!WARNING: The side door must be closed when this operation is carried out.

For the Apollo and Fiesta, both wheels may be raised off the ground by the following means:

- Unhitch the camper and lower the nose as far as you can by winding the jockey wheel.
- 2) Lower the two rear corner steadies to the ground.
- 3) Carefully raise the nose of the camper by use of the jockey wheel, until the wheels are clear of the ground.
- 4) Follow procedure above, steps 4 to 9.

!WARNING: These methods of raising the camper should only be used in an emergency and with extreme caution.



TYRE-LINE ORIGINAL EQUIPMENT LTD.

Cedar House, Sopwith Way, Daventry, NN11 5PB.

Tel: 01327 701000 Fax: 01327 701001

Email sales@tyreline.com www.tyreline.com

THE WHEEL PROFESSIONALS WORKING FOR YOU

- Sole UK distributors of Titan, Lemmerz and Vlukon caravan and trailer wheels.
- Major original equipment suppliers to the UK caravan and trailer industry.
- · Suppliers of wheels for imported caravans and trailer tents
- · Suppliers to caravan distributors.
- · Stockists of caravan and trailer chassis accessories.



HITCHING UP - STEP BY STEP

Important

Before entering the camper for any reason, make sure the corner steadies are fully wound down. Before starting your journey, check wheel nuts, tyre pressures and tyre condition. The towball should be well greased.

If you have no experience of towing, it is a good idea to take the camper out on quiet roads to get used to towing before your first outing. If possible, obtain permission to use private roads at the weekend when you know there will be no other traffic in order to practice reversing the camper.

- 1) Store the contents of lockers securely; close all doors. Make sure the table is stowed correctly and if you have a fridge, close the door securely (remember always to push the travel catch down so that its lower end fully engages the plastic bush on the top of the door before moving off). If you have food in the fridge, set it to 12v operation for the journey (see page 55 Kitchen Equipment).
- 2) If you are storing items on the floor make sure they are distributed as shown. Maximum load weight must not be exceeded and the camper nose weight must be no less than 95lbs (43kg) and preferably 110lbs (50kg). If the nose weight is less than the recommended value, it may lead to instability. The nose weight is the force acting downwards from the tow hitch (see diagram) and can be measured using a proprietary hitch weight gauge. See your Pennine dealer for details.
- 3) Check the gas bottle is secure and turned off. Close and lock the gas bottle locker lid.

- 4) Fold the camper and lock the door. Fit transit cover and raise the corner steadies fully.
- 5) Although Pennine campers can be manouvered by hand, we recommend that you reverse the towcar to the camper if practical. It will help to have someone guiding you. Secure the car hand brake.
- 6) Before hitching the camper, position the towball beside the towhitch. It is easier to move the towhitch sideways than to pull the camper forwards. Remove the towball cover and store it somewhere accessible.
 - 7) Use the jockey wheel winding handle to raise the tow hitch slightly above the towball. Position the tow hitch cup over the ball. Release the safety catch and lift the handle. Lower the cup onto the ball using the jockey wheel handle. Make sure the handle can close fully and the safety catch clicks on. If you have a hitch lock or similar device, fit it now.
 - it now.

 8) Secure the camper handbrake. Attach the breakaway wire to a suitable point on the tow bar (don't just loop it over the ball) and fasten it securely to itself using the clip.
- 9) Wind up the jockey wheel, locking it in the cut-out at the base of the tube so it can't move. Undo the tube clamp, raise the wheel assembly to its highest position and tighten the clamp firmly.
- 10) To make sure the camper is properly hitched, grip the drawbar underneath the rubber gaiter and lift it smartly. If the rear of the tow car lifts then you can be confident of a safe hitch

- 11) Connect the electrical plug; arrange the cable so it does not drag on the ground, but leave enough slack to allow for cornering.
- 12) With a helper, check the car and camper lights check rear lights, indicators, rear fog lights, brake lights and front lights on the camper.
- 13) If you are leaving site, check round to make sure you have left nothing, release the camper handbrake and check mirrors before driving away.

NOSE WEIGHT

It is recommended that the nose weight should be varied to find the optimum for towing dependant upon the actual laden weight of the camper. Experience has shown that the noseweight should be between 50 & 90kg.

Measurement of Nose Weight

The nose weight may be measured using a proprietary brand of nose weight indicator. Such equipment is obtainable at caravan dealers. Another simple method is to use bathroom scales under the coupling head with a piece of wood fitted between the coupling head and the scales, of such length that the camper floor is horizontal with the jockey wheel raised.


Stabilisers

A stabiliser should never be used to try to improve a camper/towing vehicle combination which has poor stability because the instability will reappear at higher speeds. However, a good stabiliser can make an acceptable camper/towing vehicle combination more stable and safer to handle.


Towing Vehicle's Rear Suspension

It is important that the towing vehicle's rear suspension is not deflected excessively by the nose weight on the tow ball. If it is excessive, the steering and stability will be affected.

The greater the towing vehicle's tail overhang (The distance between the rear axle and the tow ball) the greater effect the nose weight will have on the towing vehicle's rear suspension. After trying out the camper, it may be found that stiffening of the rear



suspension is necessary – but note that this may give the towing vehicle a firmer ride when not towing. There are a number of suspension aids available and advice should be sought on which to use and how to fit it.



It is important to ensure that the camper is towed either level or slightly nose down.

When reversing round a corner, start with the outfit in a straight line. Decide the direction to turn and apply the opposite lock (1) See diagram Pg 24. Watch the nearside wheel and when it stops turning and begins to pivot, apply the opposite lock (2). Make the car follow the camper round then finally straighten up (3).

Proficiency at reversing can only be achieved with practice and should first be attempted in a large open area. Courses are also run by many organisations.

Mirrors

The driver of the towing vehicle must have an adequate view of the rear. If there is no rear view through

the camper, it is essential that additional exterior towing mirrors are fitted.

Caution: Any rear view mirror must not project more than 200mm outside a) the width of the camper when being towed; b) the width of the towing vehicle when driven solo.

Note: Any rear view mirror fitted shall be 'e' marked and cover the field of view as stipulated by type approved requirements. (Regulation 33 of the Road Vehicles (Construction and Use) Regulation 1986)

Number Plate

A trailer must carry a rear number plate bearing the number of the towing vehicle and be illuminated at night. The number plate should conform to the same size and colour regulations as for cars. A reflective black and yellow plate may be used on a trailer towed by a vehicle with non-reflective plates and vice versa.

Speed Limits

Normal road towing: 50mph. All other limits apply. Motorways (including dual carriageways): 60mph.

Pulling Off

Operate the clutch smoothly. Allow more engine speed to produce the power to move the additional weight of the camper.

Avoid wear and tear on clutch and transmission by taking extra care.

Change gears smoothly.

Try not to jerk the clutch.

CAMPER HANDLING

Allow for the camper being wider than the car. Do not bump the kerb with the camper wheels. When passing other vehicles, allow more than the normal clearance for driving solo. Allow longer to get up speed to pass. Allow for the vehicle being twice its normal length. Do not suddenly swing out.

Carry out all manouvers as smoothly as possible. Use nearside wing mirror to check the camper has cleared when overtaking.

Concern for other road users – Campers are slower than most motor cars. They take up more room. However, they follow the towing vehicle 'faithfully' with hardly any cut-in on corners, so drive close to your side of the road. Do NOT hog the centre of the road.

Indicate your intentions – clearly and early. Stopping and overtaking distances are greatly increased when towing a camper.


Care in Cross Winds. Your camper/car combination can be interfered with by bow waves from large overtaking vehicles. Be prepared!

Snaking – If the camper starts to veer violently from side to side, SLOW DOWN using the engine. DO NOT BRAKE. When you have stopped, check the camper's nose weight, load distribution and ALL tyre pressures.

The fitting of a stabiliser will make a good combination even safer to handle. A stabiliser will NOT improve a combination having poor stability to any significant extent.

NOTE: In the event of fitting a stabiliser, a bolt on type of arrangement is recommended. The hitch assembly on chassis members should never be drilled without prior approval of chassis manufacturers AL-KO Kober.


Reversing becomes easier with practice. Pennine campers are equipped with an automatic reversing mechanism enabling the camper to be reversed immediately on stopping. Reversing practice should be carried out in a large open area.





Selecting a Site


- Carefully choose the pitch where you wish to place the camper. The site should be as level as possible, not under or near to trees. It should be well drained and not near possible boggy or marshy areas.
- 2) Select the site bearing in mind that you will have to move off at some future time. On sloping ground, face the camper down hill it is easier to tow off downhill, especially during rainy periods.
- 3) Level the camper laterally. This is accomplished by the use of levelling blocks (see sketch) an a spirit level placed parallel to the camper axle. Place the levelling block in front of the wheel needed to be raised to level the axle. The block should be wedge shaped, tyre width 100mm (4 inches) high and strong enough to support the weight of the camper.



- 4) With the help of a partner to watch the spirit level, tow the camper up the levelling block until the camper axle is level
- Apply the camper handbrake. Chock the camper wheels, if necessary, lower the jockey wheel to the ground and lock it into position.

NOTE: Whenever reversing into position on a downward

slope, it is essential that the camper is eased forward a few inches into the final parking position. This forward movement repositions the braking auto reverse mechanism thus allowing the hand brake to become effective when applied. If parking on steep or slippery slopes as a precautionary measure, the wheels should be adequately chocked.



Unhitching the Camper

- 1) Using the adjustment on the jockey wheel and holding up the latch of the locking device, wind up the jockey wheel until the hitch is clear of the towing vehicle ball.
- 2) Fit the towing ball cover.

NOTE: On upward facing sites when the hydraulically damped drawbar of the camper is fully extended, it will be necessary to slightly compress the drawbar to achieve a 'clean' unhitchina.

Proceed as follows;

- 1) Camper handbrake ON.
- 2) Reverse the towing vehicle JUST 1 inch to release the tension on the ball

3) Use the jockey wheel adjustment, as previously described, to unhitch the camper.

Horizontal Levelling

- 1) Place the spirit level in the doorway facing front to rear.
- 2) Wind the jockey wheel adjustment up or down until the spirit level indicates that the camper is level 'fore and aft'.
- 3) Wind down the corner steadies onto 'load spreaders' (pieces of wood 6 inches square) taking care not to lift the camper.

NOTE: Corner steadies should only be used as wheel jacks in an emergency.

It is important that the camper is correctly levelled so that the fridge, cooker, water heater etc. will operate satisfactorily.



Electrical System: Introduction

Your Pennine Folding Camper has a number of options for use

of electrical power.

A 240v mains electrical system is available as a factory-fitted option on all models. All models are supplied with a 12S lead which will supply supply 12v electrical power when plugged into the 12S socket on your car. 12v electricity is used to power the internal lights and the refrigerator when travelling.

The following sections fully describe the various options available and their safe use. If you intend to make use of one or more of the electricity options, take the time to read the following

sections carefully.

Maximum Carrying Capacity Per Pin: 16 amps Note: Please check that the wiring of your towing vehicle conforms to the following standard.

Normal 7 Pin Plug and Socket for Road Lighting

			A 11
Terminal No.	Cable Colour	Gauge	Application
1 L	Yellow	1.5mm ²	LH Indicator Lamp
2 54G	Blue	1.5mm ²	Rear Fog Lights
3 31	White	2.5mm^2	Earth
4 R	Green	1.5mm^2	RH Indicator Lamp
5 58R	Brown	1.5mm ²	RH tail, RH side,
			number plate light
6 54	Red	1.5mm ²	Stop lamps
7 581	Black	1.5mm ²	LH tail, RH side lamps

Auxiliary 7 Pin Plug and Socket (Type 125 - Grey or Wh			
Terminal No.	Cable Colour	Gauge	Application
1	Yellow	1.5mm ²	Reverse lamp
			and/or reverse brake
3	White	2.5mm ²	Return for power
4	Green	2.5mm ²	Power supply eg. interior light
6	Red	2.5mm ²	Power supply eg. tridge
7	Black	2.5mm^2	Return for fridge



Buy the best - Fit the best!


We manufacture a large range of electrical equipment specifically for the caravan, motorhome and static market. We can supply all requirements from a mains socket to a full electrical control system. We supply to the majority of the UK's caravan manufacturers as standard fitted equipment. accessories are now retail packed and include full instructions.

- Battery Chargers
- Alarm Systems
- Control Panels
- Mains & 12V Lighting
- Electrical Accessories

PRODUCT SUPPORTERS

Product Support is available throughout the UK for warranty and non-warranty service. Our team of qualified engineers is just a phone call away.

ELECTRICITY SUPPLY SCHEMATIC



12V ELECTRICS

When a 12S ancillary plug and lead is fitted to your camper and connected to the socket of your towing vehicle:-

1) Car Battery Only (On Site with Extension Lead)

12v power is supplied from the car battery to the interior light and submersible water pump. In this instance, the refrigerator must be powered from the gas supply to prevent exhausting the car battery (see page 55 – Kitchen Equipment).

2) Car Battery Only (Towing)

When the 12S lead is connected to the car ready for towing, ensure all 12v fittings in your camper are switched off, except the refrigerator, which must be switched to 12v (see page 42 – Kitchen Equipment). The live feed for this purpose must be connected via pin 6 of the 12S socket, which must be wired through a relay fitted in your car (see your Pennine Dealer or auto-electrician for details).

If your camper is fitted with 240v mains wiring, it is a good idea to stock and freeze down your refrigerator using a mains supply before starting your journey. The 12v car supply is then only needed to maintain temperature.

3) 12v Battery Fitted in Camper

Note: If leads and battery connectors are fitted;

12v power is supplied to:

- submersible water pump
- interior light (if fitted)
- blown air heater (if fitted)

In this instance, the refrigerator must be powered from the gas supply to prevent exhausting the camper battery (see page 55– Kitchen Equipment).

Selecting a Battery

We recommend the use of a fully-sealed lead-acid rechargeable battery made for leisure use. These are rated in ampere/hours (consult your Pennine dealer)

!WARNINGS

- 1) Switch off all appliances and light before battery.
- 2) Always disconnect the earth/negative terminal first and reconnect last.
- 3) Always follow the battery manufacturer's instructions.
- 4) Consult your Pennine dealer for advice.

Blackening of Tubes in Transistorised Lamps

12v fluorescent lights are designed to work for a voltage range 10-14v and give maximum light output over this voltage range.

The lights will continue to operate even if the voltage drops below 10 volts when the tube is receiving insufficient voltage to enable it to operate satisfactorily and the result is that the ends of the tube tend to blacken. If, subsequently, the lamp is run at the correct voltage, the tube blackening will tend to clear, but if the unit is continually run below the 10v minimum, the tube blackening will increase and will result in premature tube failure.

Refrigerator - 12v Supply/Relay Device

To minimise the possibility of a drained car battery due to the refrigerator being inadvertently left operating when the car ignition is switched off, it is strongly recommended that a suitable relay device is fitted in the car, in circuit with the ignition switch, so that when the engine is switched off, the refrigerator is also switched off.

Your car or folding camper dealer will advise on this.

Approximate Current Consumptions for Various Appliances (All 12v DC)

Standard Equipment	<u> </u>
Reading Lights	0.8 amps
Nitchen Light	0.8 amps
Awning Light	0.8 amps

240v Mains Electrics

Mains Electrical units, when fitted by Pennine, consist of;

- a) Residual Current Device (RCD)
- b) Transformer / Charger

When a connection is made to mains electricity, a 240v supply is fed to the RCD. The Miniature Circuit Breakers (MCBs) on the RCD connect 240v to;

5 amp - refrigeration (240v switch on)

10 amp - double switched socket outlet

5 amp - transformer / charger

From the 10A MCB, 240v is supplied to the transformer which in turn distributes 12v electricity to:-

- Submersible water pump (if fitted)
- Interior Light (if fitted)
- Battery in camper (if fitted)

The transformer is a Ranger Power Model Type PA (Permanently Attached). It provides fully controlled battery charging when required – recommended for sealed leisure batteries. The transformer is safety fused with thermal overload protection.

THE REPLACEMENT FUSE IS A LUCAS 8A (15A BLOW)

Wiring of Connecting Cable

for Mains Inlet

Your connecting cable should be approved to BS4343 (corresponding with IEC 309/CEE 17) maximum 16 amp, 3 pole socket with recessed tubes.

This cable is required to connect your camper to a mains supply onsite and is available from your Pennine dealer. It should be 25m long of twin core (brown and blue) and Earth (green/yellow), each of 2.5mm² section. Shorter cables may not reach from the site socket outlet to your camper on some sites.

!WARNING

Do not attempt to make up these cables yourself, unless you are qualified to do so.

Connecting cables must never me joined.

Connecting cables must not be coiled when in use.

If your connection cable is damaged, buy a new one.

NEVER wrap connections in polythene as condensation may form and conduct electricity.

Mains Electricity and Connection to On-Site Facility.

Important: Make absolutely sure that the 12S lead has been disconnected from the tow car before proceeding further.

 Before connecting up to a site mains supply, seek the permission of the site operator. Inform him when you disconnect too.

Check:

- a) That the mains supply is suitable for your installation and appliances ie. whether it is a.c. or d.c. and whether it is at the correct voltage and polarity (see operating instructions for RCD).
- b) That your installation will be properly earthed (see operating instructions for RCD). Never accept a supply from a socket outlet or plug having only two pins, or from a lighting outlet, and...
- c) That any residual current device in the mains supply to the camper has been tested recently.
- 2) MAKE SURE THAT THE SWITCH AT THE SITE SUPPLY POINT IS **OFF**
- 3) Remove any cover from the electricity inlet on the camper, uncoil the connecting cable and insert the female connector into the camper inlet socket.
- 4) Remove any cover from the socket outlet provided at the site supply point and connect the plug at the other end of the connecting cable to this. Turn the main switch ON at the site supply point. IMPORTANT: If you do not receive power, tell the site operator. Before connecting the camper installation to the mains supply, consult the notice at the supply outlet and check 1 a) above.
- 5) ON LEAVING THE SITE

Reverse the procedures described in paragraphs 3 and 4.

!WARNING


- IT IS IMPORTANT THAT THE MAIN SWITCH AT THE SITE SUPPLY POINT SHOULD BE SWITCHED OFF, THE CONNECTING CABLE DISCONNECTED AND ANY COVER REPLACED ON THE SOCKET OUTLET AT THE SITE SUPPLY POINT. IT IS DANGEROUS TO LEAVE THE SITE SUPPLY SOCKET OR SUPPLY CONNECTING CABLE LIVE.
- 6) Periodically, preferably not less than once a year, the electrical installation in your camper should be inspected and tested and a report on its condition obtained as detailed in the Regulations for Electrical Installations, published by the Institute of Electrical Engineers.

WARNING: Current consumption in your Pennine camper must not exceed 16 amps or the pitch permitted maximum if this is less than 16 amps.

Specimen list of appliances:

Kettle	2000W (2kW)	Approx 8.7amps
Toaster	1300W (1.3kW)	Approx 5.6amps
Microwave	1000W (1kW)	Approx 4.3amps
Colour TV	80-300W	Approx 0.4-1.3amps
Hairdryer	300W	Approx 1.3amps
B&W TV	100W	Approx 0.4amps

THE POWER MANAGEMENT SYSTEM PMS4



POWER MANAGEMENT SYSTEM PMS4

The PMS4 Power Management System is a 240 volt ac and 12 volt dc power control unit. it provides all the necessary features for control of the electrics and security in a caravan. The unit provides the following features:

Mains 240v ac -

Mains Module

with

EARTH LEAKAGE PROTECTION (RCD) OVERCURRENT PROTECTION (MCB's) REVERSE POLARITY INDICATION

12 volt dc -

FULLY AUTOMATIC TRANSFORMER / CHARGER

with

OVERCURRENT PROTECTION
SHORT CIRCUIT PROTECTION
ILLUMINATED ON OFF SWITCH
12 FUSED DC OUTPUT CIRCUITS

Mains Module

The PMS4 is designed to operate on a mains supply of 207-253 volts ac (making it ideal for use with low continental voltages). The 40 amp RCD (Residual Current Device) gives protection against earth faults and also acts as the main switch. The mains module also has three MCB's (Miniature Circuit Breakers) which are basically resetable mains fuses, to protect against overcurrent. Allocation of the MCB's is as follows:

MCB1

- Socket Outlets

MCB2

- Fridge, (Truma Ultrastore if fitted)

MCB3 (if fitted) - (extra Skt. if fitted)

Polarity Indicator

This red neon light will illuminate if the mains input to the unit has become reversed and will require correction. Note: this indicator may illuminate whilst using certain generators, this is quite normal and safe.

Using a Generator

When using a generator in conjunction with the PMS4 the following must be observed, failure to do so may result in damage to the unit:

- i) Always start the generator with the mains isolator in the caravan turned off.
- i) Allow the generator to warm up for a few minutes before energising power in the caravan, as the output voltage can be higher when cold.
- iii) Check the generator output voltage regularly to ensure it is within the specification of the PMS4 system (i.e. 230 volts+/-10%)

Specification

Mains Input

230volts+/-10%~ac

Frequency

50hz

Output voltage

13.8 volts DC

Output Current

12 amps (max)

Battery recommended

Re-chargeable lead-acid 12 volt battery, 6 cells, leisure type. 44

ampere-hours minimum

Dimensions -

Height 225mm width 360mm Depth 90mm

Product Support

Plug-In-Systems Ltd Ltd offer the customer an On-Site Service, available for both Warranty and Non Warranty repairs (on the CEC and Plug in-Systems range of equipment only). If you would like to take advantage of this service then please ring Plug -in-Systems direct on:

Hull (01482) 659309 and ask for product support.

Transformer/Charger

The PMS4 employs a fully automatic mains to 12 volt dc transformer and battery charger, able to operate with a wide range of input voltages and provide a stable output voltage even under load. The unit can provide up to 12 amps maximum, after which it will begin to shut down to protect itself.

To use the battery charger, place the switch on the top of the (unit marked 12v) to the 'on' position, it should then illuminate. Note: To charge the leisure battery the Car/Van selector switch must also be in the Van position.

12 Volt Fuses

Six fuses are provided to protect all dc circuits, the fuse allocation is shown below. Fuses must be replaced only with the specified values.

Fuse 1 Thetford Pump
Fuse 2 12v socket outlets

Fuse 3 Not used

Fuse 4 Lighting (if fitted)

Fuse 5 Ignition systems (if fitted)

Fuse 6 Trumatic E2400 (if fitted)

ELECTRICAL CONTROL MODULE ECM5

The PMS4 Power Management System is designed to be used in conjunction with a Control Module to allow switching and status display of the 12v leisure battery.

Battery Condition Meter

This battery condition meter indicates the power remaining in your caravan battery. Readings should be taken as follows:

Green region Yellow region Red region Fully charged (no charge necessary)
Adequate charge (re-charge if desired)
Low charge (turn on charger switch to re-charge).

Car/Van Selector Switch

The car/caravan changeover switch provided in this module should be used in the following way:

caravan position

When in this position dc power is available from the caravan battery to power all 12 volt electric circuits.

If the charger is switched on, the caravan battery will be charged up via the charger /transformer unit.

central position

when in this position with the charger switch on, power is provided to all 12 volt circuits via the charger/transformer only.


With the charger off all dc circuits are isolated

Note: The switch should be placed in this position when the van is being towed.

car position

The switch can be placed in this position should the caravan battery become discharged and no mains power is available.

Note: First of all the towing vehicle should be electrically connected to the caravan via the 12S socket.



Electrical Control module ECM5



WILTON ROYAL

For a buse range of quality carpets

As the UK's largest Carpet manufacturer,

Carpets International are

proud to be associated with

Pennine Leisure

Tel: 01274 222094

Carayan Uipholshery Services

Suppliers of Quality Furnishings to the Leisure Industry

E11 The Ropewalk, Station Road, Ilkeston, Derbyshire. DE7 5HX Tel/Fax: 0115 944 4430



Truma, Europe's leading manufacturer of LPG fired blown warm air systems and storage water heaters for vehicles, offers a complete range of heaters for folding campers, caravans, boats and motorhomes.

Whatever your requirements or for further information contact:

Truma (UK) Limited
Truma House, Hawkins Lane,
Burton on Trent, Staffs. DE14 1PT

Tel: 01283 511092 Fax: 01283 532128

www.trumauk.com email:sales@trumauk.com

THE GAS SYSTEM

Introduction

Your camper is fitted with a double burner hob and grill and an Electrolux RM4200 Refrigerator. and on the Pathfinder a water heater and an oven. (Operating instructions for these appliances can be found in Kitchen Equipment, pages 49, 51,53 and the water system page 41).

Liquified Petroleum Gas (LPG) is used to fuel the appliances via a regulator. There are two types of bottled LPG commonly used in the United Kingdom and Europe, Butane and Propane. Most cylinders containing Butane are blue, those holding Propane are red. The variety, sizes and shapes of gas cylinders are many. Consult your Pennine dealer for advice.

Gas Regulators

Gas cannot be supplied from the cylinder without some form of regulation. The gas regulator supplies gas to the appliance(s) at a constant pressure, independent of gas flow.

YOUR CAMPER REQUIRES A REGULATOR GIVING THE FOLLOWING PRESSURES;

28 mbar (11.2" w.g.) for Butane (L.P.) 37 mbar (14.8" w.g.) for Propane (L.P.)

!Warning – Regulators are NOT interchangeable between Propane and Butane and should be replaced every five years.

Gas Hose

Your camper is supplied with a hose to connect the regulator on the gas cylinder to the gas system inlet. The condition of the flexible hose should be checked each time the cylinder is replaced. If it shows signs of cracking, splitting or other deterioration it should be replaced. The replacement hose should conform to BS 3212.

Gas System Inlet

The gas system inlet is situated in the gas bottle locker mounted at the front of the camper. In addition, the cooker requires connection to the gas system before use.

!Warning - The cooker unit of the Apollo, Sterling, Pullman and Pathfinder, <u>must</u> be connected before turning on the gas at the cylinder.

Both ends of the gas hose must have a circlip/jubilee clip to ensure a secure, gas-tight fit.

Using LPG Safely

!WARNING: Read the following carefully;

- Before towing your camper you must ensure that gas appliances and gas cylinders are turned off. It is recommended that a refrigerator (if fitted) is operated from the 12v supply via the 12S ancillary power cable while travelling – not from bottled gas.
- 2) NEVER apply heat to a gas cylinder.
- 3) Regularly check the flexible gas hose and clips sealing the joints between hose/cylinder and hose/gas inlet.
- Make sure there are no naked lights when changing a gas cylinder. Do not smoke while changing a gas cylinder.
- 5) Make sure that each gas appliance is working efficiently to the recommendations of appliance manufacturers.
- NEVER look for a gas leak with a naked flame. ALWAYS use a soap solution when testing connections.
 - Better still call your Pennine dealer if in doubt.



These days you can go caravanning in complete comfort.
That is, as long as you take along your Calor Gas.

Calor will provide the power for heating, hot water, cooking and lighting. You can even enjoy a barbecue too.

Most caravanners choose Calor and with thousands of outlets nationwide, you're never far from a refill.

When you buy a caravan, make sure you enjoy the comforts of Calor. For more information, call **FREE 0800 626 626**.



CALOR GAS INFORMATION

Calor Gas At Your Service

Calor Gas introduced bottled gas for caravanners nearly 60 years ago and has continued to give an unparalleled service throughout Great Britain and Ireland ever since.

The Gas That Goes Anywhere

Backed by the country's largest LPG (Liquified Petroleum Gas) storage and distribution network and over 10,000 retail outlets many of which are caravan parks – Calor Gas provides portable gas for tourers and more permanent installations for caravan holiday homes virtually anywhere in the British Isles.

All Year Round Performance

The Calor Gas cylinder range now includes a range of propane as well as butane cylinder sizes to meet the needs of every caravanner, in winter and summer. Now there is even a 6kg propane cylinder available especially developed by Calor Gas for campers and caravan tourers. For those thinking of switching to propane, with its superior winter performance, Calor Gas dealers will be pleased to help.

Hot, Cool or Sizzling

Calor Gas dealers have a wide range of approved gas appliances, including cookers, fridges, water heaters, space heaters and of course, portable barbecues to add the sizzle to summer.

Safety Comes First

Calor Gas puts safety first and encourages caravanners to do the same. In particular, make sure ventilators are not blocked. If in doubt, check with your local Calor Gas dealer or phone the freephone number below.

For details of how to connect the regulator to the Calor Gas cylinder please refer to the booklet enclosed.

Calor Gas Customer Services

Calor Gas regional customer service departments are always happy to help you. CALL FREE ON 0800 626 626 and ask for 'Customer Service'.



THE WATER SYSTEM

Introduction

In order to utilise the water system of your camper, you will need two water containers; one to carry fresh water to the camper and another to allow waste water from the kitchen to be properly disposed of. There are jerrycans, folding containers and wheeled containers on the market. Ask your Pennine Dealer for advice.

The Whale Submersible Pump

The Whale Submersible Pump 12v socket/water inlet can be found towards the front of your camper. With your filled fresh water container in position, connect the water pipe and the attached plug to the 12v socket outlet.

Gently place the end with the pump attached into the water container. The Whale Submersible Pump is self-priming so is now ready for use. The operation of your tap will automatically activate the pump.

Operation of Submersible Pump - Hints

To obtain efficient running and maximum life, ensure the following;

- 1) There is sufficient water in the container; do not run the pump when dry.
- 2) All hose connections are water tight.
- There is adequate ventilation in the water container any cap fitting must have a ventilation hole of at least 5mm diameter.
- The 12v power supply is adequate low performance could result from a weak battery.
- 5) Sometimes, when refilling the water container, it is possible to

- create an airlock in the pump. As a result, the pump will run noisily and will not pump. To cure this, gently shake the hose to dislodge the air pocket in the pump.
- 6) The pump strainers should be inspected and cleaned at regular intervals.
- 7) The pump body is completely sealed and no maintenance is required.

Winter Storage (Tiptoe and Submersible Pumps)

To prevent frost damage during winter storage, the following precaution should be taken after your last outing of the season.

The complete system should be drained of water. In case of the Tiptoe pump, it is necessary to disconnect the inlet hose from the base of the pump and allow all water to drain. The submersible pump must be drained by opening the tap and allowing the water to empty completely from the pipework.

TRUMA-ULTRASTORE

liquid gas storage water heater with additional electric heating 230 v


Operating instructions

Always observe the operating instructions prior to starting! The vehicle owner is responsible for the correct operation of the appliance.

The installer or vehicle owner must apply the yellow sticker with the warning information, which is enclosed with the appliance, to a place in the vehicle where it is clearly visible to all users (e.g. on the wardrobe door)! Ask Truma to send you stickers, if necessary. Attention: always mount the cowl cap when the water heater is not being operated! Drain the water heater if there is a risk of frost! There shall be no claims under guarantee for damage caused by frost!

If connecting to a central water supply (rural or city connection) or when using more powerful pumps, a pressure reducer must be used which prevents pressures of greater than 2.8 bar occurring in the Ultrastore.

Safety/drain valve



- e) Lever position 'closed'
- f) Lever position 'drain'

Filling the Truma Ultrastore with water

- 1) Check that the safety/drain valve in the cold water intake is closed: Lever should be in horizontal position, position (e).
- 2) Open hot tap in bathroom or kitchen, with pre-selecting mixing taps or single-lever fittings set to 'hot'.
- 3) switch on power for water pump (main switch or pump switch).

Leave the tap open to let air escape while the water heater is filling. The heater is filled when water flows out of the tap.

Residues of frozen water can prevent filling if there is a frost. The water heater can be defrosted by switching on the heater for a short period (max. 2 minutes). Frozen pipes can be defrosted by heating the room.


Note: if just the cold water system is being used, without water heater, the heater tank is also filled up with water. In order to avoid damage through frost, the water contents must be drained by actuating the safety/drain valve, also when the heater has not been used. As an alternative, a shut off valve can be installed upstream of the cold and hot water connection.

Draining the water heater

- Disconnect power for water pump (main switch or pump switch).
- 2) Open hot water taps in bathroom and kitchen.
- 3) Open safety/drain valve: Lever in vertical position (f).
- 4) The water heater is now drained directly to the outside via the safety/drain valve.

Check that the water contents have been completely drained (10 litres).

Control panel (Gas operation)



- a) Slide switch On/Off
- Rotary knob for water temperature (illuminated by green indicator lamp 'operation').
- c) Red indicator lamp

Gas operating instructions

Attention: Never operate the water heater without water in it! If the wall cowl is positioned close to an opening window (or hatch) - in particular directly under it - it must remain closed when the water heater is in use (see warning plate).

- 1) Remove cowl cover.
- Open gas cylinder and open quick-acting valve in the gas supply line.
- 3) Select required water temperature at rotary knob (b) infinitely variable from approx. 30° to 70°C.
- 4) Switch on water heater at the slide switch (a) on the control panel, green indicator lamp 'operation' lights up.
- 5) If there is air in the gas supply line, it may take up to a minute before the gas is available for combustion. If the appliance switches to 'Failure' during this period, switch off the appliance - wait 5 minutes - and switch on again!

Switching off (gas operation)

Switch off the water heater at the slide switch (a).

Drain the water heater if there is a risk of frost!

If the water heater is not to be used for a longer period, mount cowl cover (non observance of this point can lead to the function of the appliance being impaired through water, dirt or insects), close quick acting valve in the gas supply line and close the gas cylinder.

There shall be no claim under guarantee if this point is not observed.

Always remove the cowl cover prior to operating the water heater!

Red indicator lamp 'Failure'

The red indicator lamp (c) lights up if there is a failure.

The reason for such an indication is, for example, no gas available or air in the gas supply system, triggering of the excess temperature monitor etc. To unlock, switch off the appliance, wait 5 minutes, and switch on again.

In the event of faults, always contact the Truma Service

Electrical operating instructions

Switch the switch marked water heater to 'on'. The indicator lamp indicates that the electrical water heater is switched on.

Attention: Never operate the Ultrastore 230 volt heating element without water contents! Don't forget to turn the appliance off when the vehicle is not being used.

If the element fails to operate 'switch off' at the mains switch to reset.

Note: The water temperature cannot be selected, automatic temperature limitation at approx 70°C! For a faster heating up period the appliance can be simultaneously operated with gas and electrical power.

Maintainance

Use Wine vinegar for de-scaling the water heater, this being introduced into the water supply. Allow the product to react and then thoroughly flush out the appliance with plenty of fresh water. To sterilise the water we recommend 'Certisil-Argento'. Other products, particularly those containing chlorine are unsuitable.

Note: The water tank in the Truma-Ultrastore is of high quality food-proof stainless steel VA. The plastic elbow water connections and the safety/drain valve fulfil the EC guideline for food quality in plastic parts (90/128/EEC).

However, in order to avoid the colonization of microorganisms, we recommend heating up the tank to 70°C at regular intervals and not using the water as drinking water.

Fuses

The water heater fuse is on the electronic control unit on the water heater.

Important note: only replace the miniature Fuse on the p.c.b. with a fuse of the same type: 1,25 AT EN 60127-2-3 (slow action).

If there is a defect in the electronics, return the control p.c.b. well padded. If you fail to pack it correctly the guarantee shall no longer be valid.

Only use original Truma-Ultrastore control p.c.b.'s as spare parts!

General safety notes

In event of leaks in the gas system or if there is a smell of gas:

- extinguish all naked flames!
- do not smoke!
- switch off the appliances!
- close gas cylinder!
- open the windows!
- do not operate any electrical switches!
- have the entire system checked by an expert!
- 1) Repair jobs are only to be carried out by an expert.
- 2) Any alteration to the appliance (including cowl) or the use of spare parts and accessories which are important for the functioning of the heater and which are not original Truma parts, as well as the non-observance of the installation and operating instructions, shall lead to the cancelling of the guarantee and exclusion of liability claims. It also becomes illegal to use the appliance, and in some countries this even makes it illegal to use the vehicle.
- 3) The operating pressure for the gas supply is 30 mbar (or 28 mbar butane/37 mbar propane) and must correspond to the operating pressure of the appliance (see data plate).
- 4) For your own safety it is absolutely necessary to have the complete gas installation regularly checked by an expert (at least every 2 years).
- 5) During the initial operation of a brand new appliance (or after it has not been used for some time), a slight amount of fumes and a slight smell may be noticed for a short while. Remedial action here to immediately run the heater and to ensure adequate room ventilation.
- 6) If the burner makes an unusual noise or if the flame lifts off, it is likely that the regulator is faulty and it is essential to have it checked.

THETFORD ELECTRONIC FLUSHING CASSETTE TOILET

Introduction

The new Thetford Cassette Porta Potti design is functional and incorporates modern sculpture styling with home-like features making it aesthetically compatible with the Caravan bathroom decor. The unit is an integral part of the caravan bathroom.

The Cassette Porta Potti is constructed of high quality plastics for durability and has a high gloss finish that is easy to clean and maintain. The unit consists of two sections, a permanently installed toilet system and a slide out waste holding tank - CASSETTE.

The toilet section includes a seat and a cover, flush and valve blade opener knob, toilet tissue compartment, a drip tray - a drain tube assembly. The unique cassette section is located underneath the toilet and is removed for emptying from outside the caravan through an access door. A rotating pour out spout, automatic holding tank vent, air release valve, valve blade, carrying handles and hand grips are incorporated into the cassette. Other features include a safety sensor switch that guards against adding water to the bowl without cassette in proper position. The Thetford Cassette Porta Potti is a unique solution to a caravan's sanitary problem.





Note: The water for flushing the toilet is supplied direct from the onboard water tank


Preparing for use

- Remove cassette by pulling straight out. When cassette hits stop, tilt downwards slightly and remove (stop for safety when cassette is full).
- 2) Position tank vertical and swivel pour out spout upward.
- 3) Remove cap. Remove deodorant from storage compartment. Add 100ml of Aqua Kem or 120ml of Aqua Kem Bio through pour out spout. Add small amount of water through spout to cover. tank bottom. Replace cap and return pour out spout to its original stored position.


NOTE: As an alternative deodorant can be added to cassette through the valve blade opening.

Hotter weather or longer retention time may require addition of more Agua Kem.

CAUTION: Do not add Aqua Kem Concentrate or Aqua Kem Bio directly into toilet bowl while cassette tank valve blade is closed. Pressure due to heat and altitude change can build up in the cassette tank causing bowl contents to splash upward upon opening the valve blade, if opened too fast. Before each use, open and shut the cassette valve blade to vent the tank.







- 4) Slide the cassette, pour out spout facing outside into the caravan through access door. Never force insertion or removal of the cassette tank, damage to the system may occur.
- 5) Make sure the cassette is secured by retaining clip, close and lock access door.

Operation

Flushing

6) Before using the toilet we advise you to add some water to the bowl by pressing down the flush knob. This avoids marking the bowl. Water will stop flowing when the knob is released.

7) To flush after use press the flush knob down while turning in an anti-clock wise direction.









The turning motion opens the valve blade, emptying the toilet bowl. This procedure results in the best bowl rinse and most efficient use of water. After flushing, turn the knob in a clockwise direction to close the valve blade. The toilet can also be used with the valve blade open, which allows the waste to go directly into the holding tank.

Toilet Tissue

 Toilet tissue is stored in the specially designed storage compartment that helps to keep the tissue clean and dry. Tissue

- can also be suspended on a tissue holder using the special wall mounted bracket if desired
- 9) To replace tissue, remove tissue holder from compartment by pulling up on tissue cover. Hold bottom of tissue holder in one hand and cover in the other, and turn in opposite directions until you hear a click. Pull apart. Place tissue on holder, insert prongs of cover into holder. Hold cover and holder and twist in opposite direction until locked. Aqua soft toilet tissue is recommended for best results.

Emptying the Cassette

The cassette capacity is 20 litres and should be emptied when the waste level gauge indicator goes from green to full red. The gauge does not begin to move to red until tank is over half full.

CAUTION: Do not allow cassette to become overfilled, see trouble shooting section for emergency emptying procedure. To empty cassette be sure that the valve blade is in the closed position.

- Open the access door on side of caravan. Depress the retainer clip, pull cassette until stop, tilt and remove cassette.
- 11) Carry the cassette using the lower carrying handle, pour out spout up, to a normal household type toilet or other authorised disposal point. Set cassette in vertical position on the ground and rotate pour out spout upward.
- 12) Remove spout cap. Grasp unit by upper carrying handle nearest to pour out spout. Place other hand on upper rear hand grip so that the air relief valve button can be depressed with thumb while emptying, to ensure smooth outflow of tank contents.

When empty, rinse tank and valve blade area with water.

NOTE: Depress air release valve button only when pour spout is pointing upwards.

13) After preparing for use, slide the cassette into the caravan. Check to make sure that the retaining clip secures the tank in a locked position. The pour out spout end of the tank should be visible through the access door opening. Add water to the fresh water tank as outlined in "preparation for use" section and close and lock access door.

Cleaning and Maintenance

No routine maintenance is required on the Thetford Cassette Porta Potti. The use of Aqua Rinse helps to clean and protect the toilet bowl, valve blade and seals during flushing. Do not use strong household detergents or cleaners with chlorine, solvents or acid contents, as they will damage seal valves. Empty cassette and rinse tank with clear water. Use a mild soap to clean toilet bowl, seat and cover, as well as exterior of toilet unit and cassette. Replace tank inside caravan. NOTE: a) pour out spout and vent plug can be removed; b) seals should be greased if necessary with acid free vaseline.

WINTER STORAGE

The Thetford Porta Potti is easily stored in winter. When the cassette is not going to be used in winter you have to carry out the winterising of the cassette in the normal procedure of winterising the caravan. Before beginning to drain the water supply system of the caravan. Open the electric valve by pressing down the flush knob while the system is under pressure. keep the flush knob pressed down while draining the water supply system.

Trouble Shooting - Problems & Solutions

Bowl does not drain when toilet is flushed. Cassette is overfilled. DO NOT REMOVE CASSETTE. While inside the caravan turn flush knob anti-clockwise to open valve blade and leave it in the open position.

Open access door on side of caravan. Rotate pour out spout outward. Place appropriate size container under spout cap. Remove cap carefully. Allow bowl contents to drain into container. This will lower the water level in the bowl. Replace cap and return pour out spout to stored position. DO NOT REMOVE CASSETTE. Go inside and turn the flush knob clockwise to close valve blade. Now, the CASSETTE may be removed following the normal removal and emptying procedure.

Toilet tissue does not fit into compartment

Since some tissues are supplied on larger rolls, it may be necessary to use some tissue before storing in the compartment.

Soiled bowl after flushing

Partially fill bowl to cover soiled portion of bowl. Next flush will dissolve waste. TIP: Leave valve blade open during use.

No power to add water to toilet bowl

Check CASSETTE safety sensor switch and fuse holder for proper engagement and operation. NOTE: CASSETTE has to be removed to reach switch and fuse. Insert CASSETTE and try adding water to toilet bowl. Toilet can be flushed manually. Add water to bowl from a separate container. Turn flush knob anticlockwise to open valve blade. Turn clockwise to close valve blade.

CASSETTE cannot be removed.

Check for obstacles under retaining clip. Depress retaining clip several times to check operation. Remove CASSETTE. Flush knob and valve blade in partial open position. Close valve blade by moving knob clockwise.

CAUTION: If valve blade is open during CASSETTE removal, severe damage to system can occur. Never force insertion or removal OF THE CASSETTE tank.

Valve blade mechanism sticks or is hard to open Spray light film of silicone on blade.

Major unit malfunction

Contact your Pennine dealer.

KITCHEN EQUIPMENT

Stainless Steel Hob Unit and Enamelled Sink With Drainer, Hob Burners

!WARNING: Do not use your hob or grill without ensuring that the lid is open, the support stay locked and the aluminium shield clipped in place.

Burners can be used for fast boiling or simmering and are controlled by safety taps of the self locking type

When lighting a burner, always make sure you apply a lighted match or piezo electric igniter before turning on the gas. With a lighted match in position, push in the tab and keeping it depressed, turn in an anti-clockwise direction to the full on position.

When turning a tap from the full on position to a low rate, turn anti-clockwise until the tap will not turn any further. This indicates the bottom of the simmer range. By turning a pakwise, a larger flame can be obtained when required. To turn off turn clockwise to the off position, when a stop will be reached then release and the tap will spring out. Try not to have burner frames spreading beyond the base of small pans since this is wastefu. Make sure that the base of every kettle, saucepan or frying pan is smooth; any roughness may damage the chrome plated support.

Pan Sizes

The unit is suitable for use with pan sizes from 10cm (4") to 22cm (8.5") diameter.

Grill

The operation of lighting and controlling this burner is the same

as for the hob burners. Place the pan centrally under the grill. The grill heats up quickly so it is unnecessary to pre-heat it unless steaks or chops are being cooked in which case a couple of minutes pre-heating improves the quality of the grill. If a pre-heat is used, the empty grill pan should be placed under the grill to protect the base lining. When the grill has heated up, remove the grill pan, load the pan and place it centrally under the grill. The grill pan grid is reversible, giving a choice of two heights. Use it in the high position for toast.

Cleaning

To keep this appliance in good condition, it should be cleaned as soon as possible after use. The stainless steel sink unit and the burner heads should be cleaned with warm water and detergent using a soft cloth or a non-abrasive liquid cleaner. Stubborn stains can be removed by Duraglit or similar products. DO NOT use harsh abrasive cleaners, steel wool or cleansing powders. NEVER insert prickers, wires etc into jets for cleaning.

Adjusting

Your unit will be supplied correctly fitted and adjusted. Any subsequent service must be carried out by a person qualified to do so.

Using Your Hob Unit Safely

- When the grill or hob is in use, always leave the front of the grill compartment open to allow hot air to escape. Always allow to cool before closing.
- 2) Always raise the hob lid, lock the support stay and clip the aluminium shield in place before using the grill or hob.

- 3) The clear plastic cover over the ventilation mesh behind the hob/sink unit should be opened while using the hob/sink.
- The grill or hob must not in any circumstances be used as a space heater.
- 5) Care should be taken to ensure that flammable materials are not in the vicinity of the burner flames.

Manufactured by; Spinflo Limited, 4-6 Welland Close, Parkwood Industrial Estate, Rutland Road, Sheffield S3 9QY Tel: (0114) 2738157

SPINFLO COOKERS

The Hob

To Light The Hob

- 1) Push in the control knob and turn anti-clockwise to the large flame symbol.
- 2) Keep the knob depressed and press the ignition button.
- Keep the control knob depressed for a few seconds after the burner has lit
- 4) until the flame is established and the flame sensing device has opened.
- 5) Turn the control knob to the required setting.

To Turn Off

Turn the control knob clockwise until the dot symbol on the control knob is next to the reference mark on the facia.

BE SAFE, NOT SORRY WHEN YOU ARE COOKING KEEP CHILDREN AWAY FROM THE VICINITY.

Turn pan handles inwards so they are out of reach of children and cannot be caught accidentally.

Avoid using pans with a diameter of less than 100mm/4ins or old mis-shapen pans which are unstable and dangerous.

NEVER LEAVE FAT OR OIL UNATTENDED ON A LIT RING.

Do not use pans with a base diameter greater than 200mm / 8ins. Using a pan that is larger than this may cause damage to the control knobs.

Always use the most appropriate size of burner for the pan you wish to use. Do not use foil on the hob as it creates a fire hazard.

The Grill

THE DOOR MUST BE OPEN WHEN THE GRILL IS USED. Never cover the grill pan or grid with cooking foil, or allow fat to build up in the grill pan as this creates a fire hazard. Keep all flammable material away from the appliance.

CAUTION: WHEN THE GRILL IS BEING USED, ACCESSIBLE PARTS MAY BE HOT - YOUNG CHILDREN SHOULD BE KEPT AWAY.

To Light The Grill

Open the door and push in and turn the control knob anticlockwise to the large flame symbol. Keep the knob depressed and press the ignition button. The knob must be held in for 15-20 seconds before releasing. Adjust to the desired setting.

Using The Grill

Push in the grill pan until it locates centrally under the grill burner.

There are three different grilling positions as the trivet can be inverted to give a high or low position or it may be removed.

- 1) The high trivet position is suitable for toasting bread.
- 2) The low trivet position is suitable for grilling all types of meat.
- 3) With the trivet removed, the food is placed directly on the base of the grill pan eg. when cooking dishes such as whole fish.

Always pre-heat the grill for 3 minutes for best results. When you have finished grilling, check the control knob is in the off position.

CLEANING

CAUSTIC PASTES, abrasive cleaning powders, coarse wire wool and hard implements will damage the surfaces.

All parts of the hob can be safely cleaned with a cloth wrung out in hot soapy water but allow it to cool before cleaning. To avoid damaging the surfaces when removing stubborn marks we recommend the following:-

Facia knobs - Only use hot soapy water.

Hotplate pan supports and burner caps – Use a mild paste cleaner which has the VITREOUS ENAMEL recommendation seal, eg. Jif, Flash or Ajax liquid, or use a moist soap pad eg. Brillo.

Burner ring – For the burners to work safely, the holes in the burner ring where the flames burn need to be kept clear of deposit. Use a moist soap pad or clean with a nylon brush, rinse and dry thoroughly.

BLOW OUT ANY WATER REMAINING IN THE HOLES.

Burner Skirt – The burner skirt is aluminium and can be PERMANENTLY DAMAGED by soaking or automatic dishwashers. Use a mild soap pad.

When replacing the pan supports, locate with the plastic clips.

THE OVEN

DO NOT use foil on the oven shelves as this creates a fire hazard.

Keep all flammable material away from the appliance.

CAUTION: When you are cooking, keep children away from the vicinity of the oven.

IMPORTANT: a safety device stops the ignition being used when the oven door is closed.

To Light The Oven

- 1) Open the oven door and turn the control knob anti-clockwise to the required gas mark. Push in and hold the control knob and press the ignition button on the facia.
- 2) Once the burner has lit, close the oven door, and hold the knob in for 15-20 seconds.

www.foldingcampers.net

3) If the flame goes out, the flame sensing device cuts off the gas supply to the burner.

To light the oven again, wait for 3 minutes and then repeat steps 1 and 2. The required gas mark setting can now be selected.

To Turn Off

Push in the control knob and turn clockwise.

Using The Oven

The oven must be pre-heated for 10 minutes when re-heating frozen or chilled food, and it is recommended to preheat for all yeast mixtures, batters, souffles and whisked sponges. If you are not pre-heating the oven the cooking times in the oven cooking guides may need to be extended as they are based on use of a pre-heated oven.

The shelf positions in the oven baking guide are counted from the top of the oven. If you prefer darker cooked results, cook on a higher shelf, for paler results, use a lower shelf.

The cake tray and roasting tin that are supplied with this appliance are the largest which can be used for good results and even baking.

Place food items on the tray and position the tray on the centre of the shelf, leaving one clear shelf position between shelves to allow for circulation of heat.

CLEANING

DO NOT USE CAUSTIC PASTES, ABRASIVE CLEANING POWDERS, COARSE WIRE WOOL OR ANY HARD IMPLEMENTS AS THEY WILL DAMAGE THE SURFACES. Clean your oven frequently to avoid a build up of soiling which will be difficult to remove.

Always clean off any spillages as soon as possible to prevent them burning on.

All parts of the oven can be safely cleaned with a cloth wrung out in hot soapy water, but let the oven cool before cleaning.

Use the following recommended cleaning methods for the various component parts and finishes of the oven.

For the vitreous enamelled parts of your oven, only use cleaners which bear the Vitreous Enamel Development Council's recommendation seal, eg. 'Jif', 'Ajax' liquid or cream.

Gold Finished Parts

Door handles – Only use a clean cloth wrung out in hot soapy water.

Glass Parts

Do not use abrasive cleaners or polishes. Use a mild cream cleaner, rinse thoroughly and dry with a soft cloth.

The lower door glass panel can be removed for cleaning, open the oven door wide, hold the bottom and top edges and slide out. When replacing the glass panel, hold it level and straight with the grooves in the door trims before sliding it back in.

Painted Parts

Only use a clean cloth wrung out in hot soapy water.

Vitreous Enamel Parts

(Grill pan, heat guard and oven/grill compartments)

Use a mild cleaner with approved seal.

Chrome Plated Parts

Do not use abrasives or polishes. Use a moist soap pad eg. Brillo.

Shelf runners can be removed for cleaning. Grasp the runners and slide out of the hanging holes.

IMPORTANT SAFETY REQUIREMENTS

Servicing

All servicing work should be carried out by an experienced and skilled person.

Important

These recommendations apply to all cooking appliances and are intended as a guide for your safety.

Do not leave the oven door open for longer than necessary when the burner is alight. The oven must not be used as a heater.

Do not leave cabinet doors open which are near to the heat source whilst any cooking appliance is in use.

Perishable foods, flammable items ie. aerosol cans etc. should not be stored in cabinets which are in close proximity to any cooking appliance. Spinflo Ltd

4-6 Welland Close

Parkwood Industrial Estate

Rutland Road,

Sheffield S3 9QY

Tel: 0114 2738157

THE ELECTROLUX RM4200 INSTRUCTIONS FOR USE

Introduction

To ensure good refrigeration and economical operation, the refrigerator must be used as described in these instructions.


The refrigerator is designed for 'built-in' installation in campers. The refrigerator can be operated from either propane or butane gas without adjustment to the appliance.


Important Information


- This product is designed to be operated by adults. Children should not be allowed to tamper with the controls or play with the product.
- Any electrical work required to install this appliance should be carried out by a qualified electrician.
- It is dangerous to alter the specifications or modify this appliance in any way.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- se proximity to any Electrolux camper refrigerators are designed to be used specifically for the storage of edible foodstuffs only.

 WWW.foldingcampers.net

- There are working parts in this product which heat up. Always ensure that there is adequate ventilation as failure to do this will result in component failure and possible food loss.
- Parts which heat up should not be exposed. Wherever possible, the back of the product should be close to a wall, but leaving the required distance for ventilation as stated in the installation instructions.
- Before defrosting, cleaning or maintenance work is carried out, be sure to switch off the appliance and unplug it.
- The ice box in this appliance contains tubes through which the refrigerant passes. If these are punctured this would cause substantial damage and result in food loss. DO NOT USE SHARP INSTRUMENTS to scrape off frost or ice. Under no circumstances should ice be forced off the ice box. Solid ice should be allowed to thaw when defrosting the appliance.
- This appliance is heavy. Care should be taken when moving it.
- Ice Iollies can cause frost burns if consumed straight from the freezer.
- Frozen food must not be refrozen once it has thawed out.
- Manufacturers' food storage recommendations should be strictly adhered to. Refer to relevant instructions.
- Do not place carbonated or fizzy drinks as it creates pressure on the container which may cause it to explode resulting in damage to the appliance.
- Under no circumstances should you attempt to repair the appliance yourself as it may lead to injury or a more serious malfunctioning.







Controls

The refrigerator can be run on either 240v, 12v or LP gas. Changing between these modes of operation is carried out by means of the control panel. (See the diagrams above).

Two rocker switches are used to select the electric power supply, one for 240v (1) and one for 12v (5).

Refrigerator temperature is controlled by a thermostat knob (2) when the refrigerator runs on 240v.

The gas supply is turned on/off by means of the knob (4). When lighting the gas, one must press in the knob as explained further on.

A manual piezo-electric igniter is used. When button (6) is pressed, sparks are generated at the burner.

STARTING THE REFRIGERATOR

CAUTION: Only one source of energy at a time.

LP Gas Operation

After initial installation, after servicing, changing gas cylinders etc., the gas lines may contain some air which should be allowed to escape by briefly turning on the refrigerator or other appliances. This will ensure that the flame lights immediately.

The flame failure device will automatically shut off gas to the burner if the flame is blown out. On electronic ignition versions the flame failure device will also shut off the gas, if the burner does not relight within about a minute of the flame being blown out.

Before You Start Gas Operation

- 1) Open the shut-off valve of the gas bottle (check that there is enough gas). Open any on-board shut-off valve.
- 2) Check that the switches for mains and 12v are off.
- 3) Depress and turn on the gas control safety device knob (4) to the gas position D.
- 4) Depress the gas control safety device knob (4) and hold it down while depressing the piezo-electric igniter button rapidly 3 or 4 times in quick succession.
- 5) Check the flame viewer to see whether the flame is alight (see Fig 2).
- Keep the safety device control depressed for a further 15-30 seconds.
- 7) Release the safety device control and check to see that the flame is alight. (See Fig 2).
- 8) To terminate gas operation, turn knob (4) to '0'.

240v Operation

- 1) Turn off gas or 12v operation where applicable.
- 2) Set switch (1) to position 1.

12v Operation

There is no Thermostatic Control on 12v Operation. Only operate your refrigerator on 12v when the engine of your vehicle is running. Install through a relay or otherwise your battery will soon be discharged.

NOTE: Before operating the refrigerator on 12v, it should be pre-cooled, together with its contents, by running it on bottled gas or 240v for a few hours before changing over to 12v and starting on a journey.

- 1) If applicable, turn off the gas operation.
- 2) Set the 240v rocker switch (1) to '0' and the 12v switch (5) to 1.

Winter Operation

If the refrigerator has been left switched off in an unheated camper when the outside temperature is below -12C, the cooling unit will become so cold that it cannot be started in the 240v mode of operation. In such an event, the refrigerator must be started on LP gas.

Some ventilator grills have a facility for winter cover (ask your dealer). These covers should be fitted in winter conditions to avoid over freezing of the refrigerator. The covers can also be used when the camper is in storage or is being washed by a high pressure spray. Remember to remove the winter covers at all other times when the refrigerator is in use.

Regulating The Temperature (See Fig 1)

Once the refrigerator has been started up, it will take a few minutes to become cold. On 240v operation, the refrigerator is controlled by a thermostat and the thermostat knob (2) should be set at 3. If a lower (colder) temperature is desired, set the thermostat to a higher number. If less cooling is required, set to a lower number.

On LP gas operation, the refrigerator is regulated by the gas thermostat knob (4), which should be set at B. This setting provides a suitable refrigerator temperature in warm weather. Should the storage compartment for fresh items grow cold, particularly in cold weather, set the valve to A. Do not forget to restore it to C or D if the weather turns cold.

On 12v operation the refrigerator works continuously.

Travel Catch (See Fig 3)

Make sure that the travel catch is engaged when the camper is on the move. The travel catch at the top of the door can be set in two different positions. In one position, the door is held tightly shut. In the other position, the door is secured ajar so that the refrigerator can be aired when not in use.

Food Storage

Always keep food in closed containers. Never put hot food in the refrigerator, allow it to cool first.

Never keep items in the refrigerator which might give off flammable gasses.

The temperature within the frozen and fresh food compartments will be affected by the location of the refrigerator, the ambient temperature and frequency of door opening. It may be necessary to adjust the thermostat setting to allow for these factors.

The 2 star (**) frozen food compartment is intended for the storage of frozen foods and for making ice. It is not suitable for freezing items of food.

Most kinds of frozen food can be stored in the frozen food compartment for about a month, This period of time may vary, however, and it is important to follow the instructions on the individual packing.

<u>Defrosting</u>

Frost will gradually accumulate on the refrigerating surfaces. It must NOT be allowed to grow thick as it acts as an insulator and adversely affects refrigerator performance.

Check the formation of frost regularly every week and when it is about 3mm thick it will be necessary to defrost the refrigerator.

To defrost the refrige<mark>rator, turn</mark> it off and remove the ice tray and all food items.

Any frozen foods should be wrapped loosely, but completely, in several layers of clean newspaper. Remember that if the temperature of frozen foods is allowed to rise unduly during defrosting then its storage time may be shortened.

If desired, defrosting can be speeded up by filling the ice tray with hot water and placing it in the frozen food compartment.

Do not try to accelerate defrosting by using any kind of heating device as the plastic surfaces of the refrigerator may be damaged. Neither should any sharp object be used to scrape off the ice.

The defrost water from the cooling plate in the fresh food compartment runs from a collector channel down a tube to a drip tray at the rear of the refrigerator where it evaporates. This does not apply to the frozen food compartment which needs to

www.foldingcampers.net

be cleaned manually. Do not refreeze any thawed frozen food. When all the ice has melted, wipe the frozen and fresh food compartments dry and leave the door ajar for airing prior to restarting.

Place the food items back inside, but wait until the refrigerator is cold before making icecubes.

Cleaning the Refrigerator

Clean the inside of the refrigerator regularly to keep it fresh and hygienic.

Soak a cloth in a solution consisting of a teaspoon of bicarbonate of soda to half a litre of warm water. Wring out the cloth and use it to clean the interior of the refrigerator and its fittings.

Never use detergents, scouring powder, strongly scented products or wax polish to clean the interior of the refrigerator as they may damage the surfaces and leave a strong odour.

The exterior of the refrigerator should be wiped clean now and again, using a damp cloth and a small quantity of detergent, but not the door gasket which should only be cleaned with soap and water and then thoroughly dried.

The cooling unit behind the refrigerator ought to be cleaned with a brush from time to time, but make sure that the refrigerator is switched off when doing this.

Turning Off The Refrigerator

If the refrigerator is not in use for some time:

- 1) Turn off the LP gas and electric power.
- 2) Empty the refrigerator and defrost it.
- 3) Clean the refrigerator interior and accessories and wipe them dry afterwards.

4) Leave the door ajar. It can be secured in this position by means of a travel catch.

If The Refrigerator Fails To Work

Check the following points before calling a service technician;

- 1) That the 'starting the refrigerator' instructions have been followed correctly.
- 2) If it is possible to start the refrigerator on any of the connected sources of energy.
- 3) If the refrigerator fails to work on gas, check that;
 - The gas bottle is not empty.
 - That all LP gas valves are open.
- 4) If the refrigerator fails to work on 12v, check that;
 - The 12v supply is connected to the refrigerator.
 - The fuse on the 12v supply is intact.
 - That the 12v switch is on.
- 5) If the refrigerator fails to work on 240v, check that;
 - The 20v supply is connected to the refrigerator.
 - The fuse is intact.
 - That the 240v switch is on

If the refrigerator is not cold enough, it may be because;

- 1) The ventilation is inadequate owing to objects such as wire mesh or winter covers blocking ventilation passages.
- 2) The evaporator is frosted up.
- 3) The temperature control setting is incorrect.
- 4) The gas pressure is incorrect check the pressure regulator at the gas container.
- 5) The ambient temperature is too high.
- 6) Too much food is loaded at the same time.

- 7) The door is not properly closed.
- 8) More than one source of energy is used at the same time.

The sealing cooling system must not be opened, since it contains corroding chemicals under high pressure.

FAILURE TO OBSERVE THESE CHECKS AND THOSE SHOWN ON THE DOOR PANEL INSTRUCTION LABEL COULD ALL RESULT IN YOU BEING CHARGED FOR THE SERVICE CALL.

Some Useful Hints

Make sure that;

- The refrigerator is not operating on 12v when the vehicle is parked, otherwise you may drain the car battery in a short time.
- Defrosting is carried out periodically.
- The refrigerator is clean and dry with the door left open when it is not in use.
- The ventilation openings are not obstructed.
- The door is secured by means of a travel catch when the camper is on the move.
- Only one mode of operation at a time is used to run the refrigerator.

MAINTENANCE

Couplings can be tested for leaks using a soap solution.

DO NOT USE AN OPEN FLAME!

If there is any suspicion of damage, call for a service engineer.

In order to maintain optimum performance, it is recommended that this appliance is inspected and serviced annually by a qualified person.

Technical Data

Model	PM 4200
Overall Dimensions:	
Height	615mm
Height	514
Width	400
Depth with door	46∠mm
Depth without door	482mm
Depth without door	443mm
Height	/10
Width	ol3mm
Depth	·····490mm
Depth	460mm
Gross Vol. (Approx.)	60 Litres
Weight (Max.)	17ka
	J


OPTIONAL BLOWN AIR HEATING

Trumatic E 2400 L.P.G Heater

Operating Instructions

Always observe the operating instructions and "Important operating notes" prior to starting! The vehicle owner is responsible for the correct operation of the appliance. The installer or the vehicle owner must apply the yellow sticker with the warning information, which enclosed with the appliance, to a place in the vehicle that is clearly visible to all users (e.g. on the wardrobe door)! Ask Truma to send you stickers, if necessary.

Control panel with thermostat



- a) Slide valve Heating -Off- Ventilation
- b) Slide valve for high setting (large flame symbol) and low setting (small flame symbol)

Switching on the Heating

- Turn on the gas cylinder and open quick-acting valve in the gas supply line.
- 2) Adjust desired room temperature at rotary knob.

3) Switch the slide valve (a) to heating and slide valve (b) to the desired output setting. If the outside temperature is low, switch to high setting.

Switching on the Ventilation

Switch the slide valve (a) to Ventilation switch the slide valve (b) to high setting or low load.

Switching Off

Move the slide valve (a) to middle position. If the appliance is switched off after a heating phase, the fan can continue running in order to make use of the residual heat.

If the appliance is not used for a prolonged period of time, mount the cowl cap, close quick acting valve in the gas supply line and turn off gas cylinder

Green Indicator lamp Operation (under rotary control knob)

When the appliance is switched on (heating or ventilation) the green indicator light must be illuminated (the fan is running). If the indicator light is not illuminated, possibly check the (main) switch. For this purpose observe respective instructions of the vehicle manufacturer. During the heating operation, while the flame is burning, the green indicator lamp lights up with twice the intensity. This also makes it possible to determine the instantaneous switching point of the room temperature.

<u>Fuses</u>

The appliance fuses are situated on the electronic P.C board on the appliance.

Important note: Only replace the miniature fuses F1 and F2 with a fuse of the same type:

F1 = 3,15 AF EN 60127-2-1 (fast) F2 = 1,25 AF EN 60127-2-2 (fast)

Red indicator lamp Failure

Should a failure occur, the red indicator is illuminated permanently. Possible causes for the failure can be e.g no gas, insufficient combustion air, heavily soiled rotor, defective fuse etc.. Deactivate by switching off and then switching on again.

Flash Operation indicates that the operating voltage is too low or too high for the appliance (change battery, if necessary)

Accessories

- Time switch ZUE For pre-programming 3 switch-on times within 7 days, including 4m connecting cable (suitable for 12v and 24v vehicle electrical system).
- Remote sensor FF Monitors the room temperature independent of the position of the control panel (available with 4m or 10m connecting cable).
- Multiple connector MSD For connecting several accessories (e.g. time switch and remote sensor).

All electrical accessories are fitted with a connector and can be connected individually.

Important operating notes

- Following a blow-back (misfire) always have the exhaust gas system checked by an expert!
- 2) Always keep the cowl for conducting exhaust gas and

- supplying combustion air, free from contamination (slush, leaves etc.).
- 3) The installed temperature limiter shuts off the gas supply if the appliance becomes too hot. Therefore do not shut the warm air outlets and opening for the returning circulating air.
- 4) If the electronic control p.c.b is defective, return it well packed. If you fail to do so, guarantee claims shall no longer be valid. Only use original p.c.b as a spare part! The vehicle owner is the person responsible for arranging the inspection and the replacing of the parts.
- 5) For conducting the exhaust gas under the floor, the vehicle floor must be sealed tight. There must also be three open sides beneath the vehicle floor to ensure unhindered escape of the exhaust gas (snow, aprons etc).

General safety notes

If the gas system is leaking or if there is a smell of gas: extinguish all naked flames

- Do not smoke
- Switch off the appliances
- Shut off the gas cylinder
- Open the windows
- Do not actuate any electrical switches
- Have the entire system checked by an expert.
- 1) Repairs may only be carried out by an expert.

Attention: A new O-ring must always be installed after dismantling the exhaust duct!

- 2) Any alteration to the appliance (including the exhaust duct and cowl) or the use of spare parts and accessories which are important to the function of the heater and which are not original truma parts, as well as the non observance of the installation and operating instructions, will lead to the cancelling of the guarantee and exclusion of liability claims. It also becomes illegal to use the appliance, and in some countries this even makes it illegal to use the vehicle.
- 3) The operating pressure for the gas supply is 30 mbar (or 28 mbar butane/ 37 mbar propane) and must correspond to the operating pressure of the appliance(see name plate).
 The vehicle owner is always responsible for arranging the inspection.
- 4) For your own safety it is absolutely necessary to have the complete gas installation regularly checked by an expert (every 2 years at the latest).
- 5) During the initial operation of a brand new appliance (or after it has been used for some time), a slight amount of fumes and smell may be noticed for a short while. This can be remedied by running the heater at maximum output and ensuring adequate room ventilation.
- 6) If the burner makes an unusual noise or if the flame lifts off, it is likely that the regulator is faulty and it is essential to have it checked.

Advanced Thermofo Thermofo Technology

Delighted to supply **Pennine Leisure**

Working with leading
European manufacturers to
set international standards
in touring caravan design
and production.



Thompson Plastics (Hull) Limited

Bridge Works, Hessle, HU13 0TP Tel: 01482 646464 Fax: 01482 644446

Plastics (Manchester) Limited

Peter Moss Way, Levenhulme, Manchester M19 3PX Tel: 0161 257 2929 Fax: 0161 257 3203 www.thompson-plastics.co.uk

Caravan Exteriors

- front and rear panels
- hitch covers
- wheel spats

Caravan Interiors

- bathrooms
- shower enclosures
- kitchen sinks
- accessories





CARING FOR YOUR PENNINE

Exterior Panels

The exterior panels of your camper are acrylic painted aluminium sheets which are very easy to keep clean. We recommend that you wash down with plenty of clean water and a **mild** detergent. The most effective cleaning aid is either a short-haired bristle brush or a piece of tufted carpet. Polish occasionally with a good quality wax to help obtain a high gloss finish.

NEVER USE ABRASIVE OR HARSH CLEANERS

Use white spirit to remove stubborn marks such as tar or grease.

Corner Mouldings

Mouldings are anodised aluminium and should be treated in the same way as exterior panels. Examine mouldings regularly to ensure that no gaps have appeared which could allow water in. If gaps should appear, they may be sealed with mastic (contact your Pennine dealer if you are unsure)

Gas Bottle Locker

This is made from Glass Reinforced Plastic (GRP) and should be cleaned with detergent and water and waxed regularly.

Canvas

Before use, your canvas requires weathering. Once the canvas is weathered as described, it will be fully waterproof.

Avoid allowing aerosol sprays to come into contact with the canvas, as this may adversely affect its waterproof qualities. Mud and light soiling should be brushed off when dry. If necessary, a

weak solution of pure soap flakes may be used to remove stubborn marks. It is important, if this is done, to clean a complete panel of canvas, rather than a small area, to avoid watermarking.

Interior

For upholstery, a proprietary dry cleaning fluid will remove most stains; pre-treatment with a mild soap and water may be necessary for more stubborn stains, Brushing or vacuuming regularly will keep upholstery looking at its best. Fabric snags should be trimmed off immediately. Never attempt to pull them off as this could cause even more damage.

Carpeting, where fitted, should be regularly brushed while on site and vacuum cleaned on returning home to ensure particles of mud and grit do not become embedded.

Use a damp cloth to remove finger marks from furniture, or an all purpose cleaner. Furniture polish may be used, but do not use oil or abrasive cleaners.

Cupboard catches, stays and hinges, should be kept clean and lightly oiled or smeared with vaseline or alternatively silicon spray.

Use a mild detergent and damp cloth to remove any finger marks from interior wall boards.

Curtain Care Instructions

Curtains may be dry cleaned or washed as follows;

- Wash separately by hand or machine in luke warm water, not exceeding 40C.
- 2) If by machine, use delicate fabric programme.
- 3) Finish with cold rinse and short spin.
- 4) Line dry.
- 5) Steam Iron with setting on cotton.

- 6) Only pure soap solution should be used.
 - a) Do not use bleach.
 - b) Do not use detergents.

Shower Room and Wash Basin Fittings

Always use a non-abrasive cleaner. Always put the cold water into the wash hand basin BEFORE adding the hot water in order to preserve the finish of the thermoplastic basin.

WINTER STORAGE

If the environment in which the camper is to be stored is likely to be damp, it is best to remove the canvas and store it in a warm, dry place. In any case, the inner tents, curtains and mattresses should be removed and stored inside.

To remove the canvas:

- Unfold beds. Unfasten the three screws securing the canvas to each bed board. Unfasten the canvas ties from the frame where applicable.
- Carefully remove and roll up the canvas, ideally packing it into a polythene bag. NOTE: Make sure that the canvas is absolutely dry before you do this.

Location

Ideally, your Pennine camper should be stored undercover, protected from the elements but in a location which allows free circulation of air. If an undercover location is not available, the camper should be sited on firm ground with adequate drainage and not too exposed. Avoid storing under trees or in areas where it might be subject to accidental damage.

Storage Checklist

- 1) Remove inner tents, curtains and mattresses and store safely indoors. Vacuum and clean the interior of your camper.
- Clean and polish the cooker hob. Ensure cupboards are clear
 of food or crumbs as vermin could be attracted if they are left.
- 3) Clean out the fridge (if fitted) with bicarbonate of soda and leave the door in its 'vent' position.
- 4) Clean and sterilise the water system, pipework and containers by flushing with a suitable solution (eg. Milton) and rinsing. The containers can be stored inside the camper. Drain the water system before the risk of frost damage.
- 5) Stand the camper with towbar end higher than the rear to allow any water to run off. NOTE: Do not allow water, ice or snow to collect on top of the camper as it will discolour the transit cover.
- 6) If you wish, you may jack up the wheels and support the camper on blocks or axle stands, being sure to support the camper on blocks rather than drop arms so that the load is taken off the suspension. Alternatively, wind down the corner steadies so that the bulge at the bottom of the tyres is taken out.
- 7) Release the handbrake to prevent the brakes seizing onto the wheel drums. Rotate the wheels occasionally to keep the bearings lubricated.
- 8) Examine the plug(s) and cables for corrosion or damage. Replace any damaged cables and corroded pins or grubscrews. All round terminals should be cleaned with fine emery paper and brass cleaner and finally smeared with petroleum jelly.
- 9) Wash the exterior periodically.

POINTS TO NOTE

Chassis

Apply lithium based grease to the corner steady joints and screw threads also to the tow-hitch and the car's towball (then fit the towball cover). Lubricate the jockey wheel.

AL-KO Galvanised Chassis & Wet Storage Stain (Rust)

Hot dip galvanising has been used for many years throughout the automotive industry, and is widely regarded as one of the best forms of corrosion protection. It does, however, need minimal maintenance in certain circumstances.

In its natural state, zinc is not a corrosion resistant metal, it achieves its corrosion resistance by forming a barrier layer through reaction with the atmosphere. This is mainly caused by the CO₂ content forming zinc carbonates.

The shiny silver colour of Hot Dip Galvanising will, over a period of time, turn light grey. This does not denote a failure of the galvanising, but simply shows the formation of the protective layer of zinc compounds.

These protective layers cannot form as a part of the curing process on material newly galvanised if the surface is covered with moisture of a low mineral content such as condensation, rain water or thawing snow. Insufficient air circulation will also prevent formation of these layers.

These are exactly the conditions experienced during long term parking or pre-build storage of chassis components where such moisture cannot be avoided. Restriction of air circulation can result in the formation of a soft, porous light grey oxidisation layer. This is known as 'White Rust' and, in this context, should not be confused with rust as applied to steel.

Light white rust deposits do not affect the performance of Hot Dip Galvanised Steel, as the deposits are transformed into a protective layer by the action of CO₂. This does, however, require good air circulation.

AL-KO, therefore, strongly recommends that camper manufacturers should ensure a clean chassis prior to dispatch and advise their dealers that upon receipt of a camper, the chassis should be washed with clean water to prevent the formation of any white rust. THIS IS OF PARTICULAR IMPORTANCE TO ANY DELIVERIES MADE DURING THE WINTER, WHEN LOW MINERAL CONTENT MOISTURE EG. ROAD SPRAY, IS MORE COMMON.

Should any light deposits of white rust be found while washing the chassis, they can easily be removed by use of a wire or hard nylon brush.

<u>Tyres</u>

Check tyre pressures regularly during storage and re-inflate if necessary. In addition, check for cracks, splits or bulges. If in doubt, replace with tyres of identical specification. (See Page 19 – Servicing and Tyre Information).

Preparation for Re-use

- Sterilise water system pipework (See page 41 Water System) and container. Check water system for leaks **before** first using the camper.
- 2) Check the gas system for leaks and general condition (See page 37 Gas System).
- Check the operation of internal 12v electrical system and mains electrical system (if fitted).
- Check the operation of 12N and/or 12S plugs, leads and sockets.

- 5) Check the operation of the roadlights.
- 6) Check the operation and adjustment of the handbrake (see page 13 Service and Maintenance or refer to your Dealer).
- 7) Check the security of the towing bracket and ball hitch. The ball hitch must be clean and well greased.

SECURITY

You will appreciate that total security of your camper is impossible to achieve. However, there are several means by which you can deter the opportunist thief and protect your property.

General Security

- 1) Always lock the door and zip up the canvas whenever you leave the camper unattended.
- 2) Remove any valuable or portable items when you leave your camper. Note for all small items, a secure locker is available from Pennine as an optional extra.

Protecting Your Camper From Theft

- Always use a hitchlock, which will delay anyone attempting to tow away your camper or unhitch it from your car. There are various types available, some of which are very inexpensive. Pennine make a wheel clamp which is designed specifically for Pennine Campers. See your Pennine dealer for details.
- Corner steadies can be locked in the down position by means of various devices available from your dealer. A wheelclamp is perhaps the ultimate method of preventing your camper from being stolen.
- 3) Keep the gas bottle locker lid padlocked at all times.

IN CASE OF FIRE

- 1) Get everyone out of the camper.
- 2) Call the fire brigade.
- 3) Turn off outside gas valve and remove cylinders away from the camper if possible.
- 4) If it is an electrical fire, always turn off the supply as quickly as possible.
- 5) Tackle the fire if it is safe to do so:
 - i) From outside the camper, NOT inside.
 - ii) Stand back about 6ft aiming the extinguisher.
 - iii) Always aim the extinguisher at the base of the fire, not the
 - iv) Once the extinguisher is empty, shut the camper and wait for the fire brigade. Do NOT go back into the camper, even if the fire appears to be out, there is always danger of re-ignition.

FIRE PRECAUTIONS

- 1) Keep a torch handy for emergencies, never use a naked flame.
- 2) Turn off all appliances and the gas bottles before going to bed or leaving the camper for some time.
- 3) Combustible materials should be kept clear of all heating and cooking appliances.
- 4) Do not leave fat pans unattended.
- 5) Do not leave children alone in the camper.
- 6) Keep matches out of children's reach.
- 7) Do not smoke in bed.
- 8) Do not block up any air vents.
- 9) Have gas piping and electrical wiring checked annually.

10) If a gas leak is suspected, use soapy water and look for bubbles – never use a naked flame. Better still – call your Pennine dealer. For extra safety, consider fitting gas detection equipment.

Fire Extinguisher

- Always carry a fire extinguisher mounted in a visible position close to the door.
- A dry powder extinguisher (minimum capacity 1kg) is recommended. This will deal safely with fat or electrical fires. (Water extinguishers should not be used for these types of fire: and vapourising extinguishers should not be used in the confined space of a camper).
- Read the instructions and make sure you and your family understand how to use your extinguisher or fire blanket before fire breaks out. Make sure that everyone in your family including children, know what to do if a fire starts.
- A fire blanket is a useful complement to your fire extinguisher.

BEFORE YOU TACKLE A FIRE

Many people put out small fires in their campers quite safely. By doing so they prevent serious injury or damage. But some people are injured and even die while trying to tackle fires which should have been left to the experts. Here is a simple fire fighting code to help you decide whether to put it out or get out.

- Always get everyone out and call the fire brigade. Only tackle a fire in the very early stages.
- Always put your own and other people's safety first and never risk injury to fight fires. Always make sure you can escape if you need to and remember that smoke can kill. IF IN DOUBT - GET OUT.

- Tackle the fire from the outside doorway, NOT inside. Never let a fire get between you and your way out. If you have any doubt whether your extinguisher is suitable for the fire, do NOT use it, GET OUT.
- Always remember that fire extinguishers are only for 'first aid' fire fighting. Never tackle a fire if it is starting to spread to other items of the camper or if the camper is filling with smoke. IF IN DOUBT, GET OUT.
- If you cannot put out the fire, or if your extinguisher runs out

 some last for only a few seconds get out of the camper immediately. Close door.
- DO NOT go back into the camper even if the fire appears to be out, there is a danger of reignition.

Don't risk injury to fight fire. IF IN DOUBT, GET OUT. Make sure the fire brigade has been called.

FIGHTING SOME TYPICAL FIRES IN A CAMPER

Chip Pan Fires

- Leave the pan where it is.
- 2) Turn off the heat if it is safe to do so.
- Protecting your hands, place a damp cloth, a close fitting lid or a fire blanket over the pan to smother the flames.
- 4) Leave the pan to cool for at least 30 minutes. The fire can start again if the cover is removed too soon.

WARNING: NEVER USE WATER OR ANY TYPE OF EXTINGUISHER TO FIGHT THE FIRE

Furniture Fires

Use an AFFF (Aqua Film Forming Foam) or a water extinguisher.

WARNING: Fires in upholstered furniture will take a long while to start because of the fire retardant properties of the fabric and foam. But once alight it can spread quickly and produce poisonous fumes. Do not tackle the fire if it is burning fiercely or if there is already thick smoke. Get out and shut the door.

Curtain Fires

- 1) Use an AFFF, water or multi-purpose dry powder extinguisher.
- Once the flames are out, make sure there is no smouldering material.
- 3) If it is safe to do so, pull the curtains to the floor.

WARNING: FIRES IN CURTAINS CAN SPREAD VERY QUICKLY

Electrical Appliances

- 1) If possible turn off the power (pull out the plug or, if you cannot reach the socket safely, switch off at the mains).
- 2) Use a halon 1211 (BCF), CO₂, AFFF, multi-purpose dry powder or water extinguisher.

WARNING: Do not use water-based extinguishers (including AFFF) unless the appliance is disconnected from the mains. You may risk electric shock. Dry powder does not penetrate the spaces in equipment easily and the fire may flare up again.

Fires Involving Bottled Gas

- Call the fire brigade immediately and tell them bottled gas is involved.
- 2) If it is safe to do so, turn off the gas supply at the cylinder valve, and remove cylinders away from the camper if possible.
- 3) Wait until the flow of gas has stopped.
- 4) Extinguish other burning materials as instructed.

WARNING: Only deal with minor fires involving bottled gas. There is a risk of explosion if a fire involving escaping bottled gas is extinguished before the flow of gas has stopped, or if the cylinder is heated in the flames.

Car Fires

- 1) Switch off the engine.
- Get everyone away from the vehicle.
- 3) Use an AFFF, halon 1211 (BCF), multi purpose dry powder or CO₂ extinguisher from outside the car, at a safe distance.

WARNING: Call the fire brigade and leave the area at once if the fire begins to develop quickly. (There is a danger of explosion if the petrol tank catches fire).

Space Heating Fires

Heating appliances should be completely extinguished before the camper is moved, and should not be used when the camper is in motion. Portable heaters or any other appliance other than the space heater should not be used to heat the camper.

Awning Spaces LPG Appliance Exhaust

Space heaters using liquified petroleum gas have a high output and are continuous burning and therefore produce a high volume of exhaust. They should not be used if their flue outlets discharge into an awning space which is fully enclosed and which people are occupying.

Instantaneous water heaters also have a high output but are used only intermittently. When they are being used, fresh air circulation has to be provided within any space covered by an awning into which their flues discharge.

There is no danger of exhaust gas pollution in awning spaces from refrigerators and storage water heaters which vent into them, but some fresh air circulation in the space should be provided.

PENNINE OWNERS' CLUB COME AND JOIN US

Buying a Pennine is merely the beginning of what will be a long relationship between you, the customer, and Pennine.

Sharing your experiences of life under canvas with others is all part of the fun of camping. The pleasures that this camaraderie provides is the reason why Pennine have firmly supported the development of the Pennine Owners' Club. An exciting venture started in 1993 by extremely enthusiastic Pennine users.

From the original seed of an idea, prompted by the enjoyment they were getting from their Pennines, has grown the Pennine Owner's Club. A highly organised club with a growing membership from all over the country and all walks of life.

The aim of the club is to provide social and leisure activities for the mutual enjoyment and benefit to all Pennine Folding Camper Owners. As the club goes from strength to strength a full programme of varied activities is planned to take place all year round.

Tours of the Pennine factory at Accrington are organised whilst the impressive sight of hundreds of Pennines at the many rallies held by the club both in the UK and on the continent are an unforgettable experience indeed.

Complementing this active programme, the Pennine Owners' Club offers many other exciting reasons for joining. Discounts on product insurance, quarterly news magazines and regular updates on product information are just part of the many services open to club members.

The emphasis at the Pennine Owners' Club is very much placed on the family atmosphere, choosing sites with good facilities and with plenty of opportunities to keep all the family fully occupied.

Significantly, the spirit of involvement fostered by the Pennine

Owners' Club has played a key role in the product development programme at Pennine's factory. Practical suggestions and tips from members have been incorporated into many of the new products. Proof indeed that at Pennine we listen.

Join us now for;

- Fun and friendship for all the family.
- Discounts on folding camper and holiday insurance.
- Organised Rallies in the UK and Europe.
- Quarterly Newsletter with news and technical advice from Pennine Leisure.

For Further Information Contact:

Membership Secretary c/o Pennine Leisure Products Ltd. Chester Street,

Accrington, Lancashire BB5 OSD

Telephone: (01254) 385991 (24 hours answerphone)

THERE IS NO BETTER CHOICE...

Trailer Tent & Folding Camper Specialists



Pennine Leisure

Dome Tents
Tunnel Tents
Touring Tents
Baggage Trailers

The Souths leading distributors of new and used Pennine & other leading makes

(023) 8046 3903

LEISURE-TRAIL Solent Ltd Haskins Garden Centre Complex, Mansbridge Rd, West End, Southampton. (A27)

Produced for Pennine Leisure Products by
Voice Publishing, 15 Tranby Lane, Anlaby, Hull. Telephone (01482) 659052

HIGHBRIDGE

Caravan Centre

EMail: info@highbridge-caravans.co.uk

THE SOUTH'S PREMIER DEALER FOR PENNINE FOLDING CAMPERS, SO FOR THE BEST DEAL ON NEW & USED CALL US FIRST

Pennine Leisure

lidlands London AWNINGS eston-super-Mare Highbridge (J22) FOR CARAVAN & CAN DING Exeter

HIGHBRIDGE CARAVAN CENTRE LTD A38 BRISTOL ROAD, HIGHBRIDGE, SOMERSET

TEL 01278 782725

OPEN 7 DAYS A WEEK

HIGHBRIDGE
CARAVAN CENTRE
HIGHBRIDGE A38

BURNHAM-ON-SEA
WESTON-SUPER-MARE

EXETER - TAUNTON M5

22 BRISTOL

www.foldingcampers.net