AWNING EXTENSION INSTRUCTIONS

PARTS LIST

- 1 off Centre Bend
- 2 off Corner Bends
- 2 off Upright Legs

- 2 off Roof Tensioner
- 1 off Extension Canvas
- 2 off Guy Ropes
- 2 off Rain Cowls
- 1. Assemble the centre bend and two corner bends. Insert the two upright legs into the corner bends. (This operation can be done laid on the ground).
- Secure the two roof tensioners onto the end roof tensioner of the awning by means of the adjustable tube clamps. (These clamps do not need:to:be tightened up yet).
- Stand up the assembled frame and clip the 'C' clips of the roof tensioners to the corner bends.
- 4. Set all the telescopic sections so that the frame looks approx the right size.
- 5. Fit the canvas over the frame and locate the eyelets on the top corners over the spikes on the corner bends.
- 6. Zip the extension canvas to the main awning canvas from inside.
- 7. Now finally adjust all the telescopic sections so that the canvas is gently tensioned. Tighten the adjustable tube clamps.
- '8. Peg down the extension using the pegs that are provided through the rubber tension rings. Fit rain cowls over spikes protruding through eyelets.

DO'S AND DONT'S

As per awning instructions.

www.foldingcampers.net

AWNING EXTENSION

S -

